

# DI

## SECTION

### DRIVER INFORMATION SYSTEM

## CONTENTS

<b>PRECAUTIONS</b> .....	<b>3</b>	Fuel Gauge Pointer Fluctuates, Indicator Wrong Value or Varies .....	24
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	Fuel Gauge Does Not Move to FULL Position .....	24
Precautions for Battery Service .....	3	Electrical Components Inspection .....	25
<b>COMBINATION METERS</b> .....	<b>4</b>	FUEL LEVEL SENSOR UNIT .....	25
System Description .....	4	Removal and Installation for Combination Meter ...	26
UNIFIED METER CONTROL UNIT .....	4	REMOVAL .....	26
UNIFIED METER AND A/C AMP. ....	4	INSTALLATION .....	26
POWER SUPPLY AND GROUND CIRCUIT .....	4	Disassembly and Assembly for Combination Meter..	26
SPEEDOMETER .....	4	DISASSEMBLY .....	26
TACHOMETER .....	5	ASSEMBLY .....	27
WATER TEMPERATURE GAUGE .....	5	<b>TRIPLE METERS</b> .....	<b>28</b>
FUEL GAUGE .....	6	System Description .....	28
ODO/TRIP METER .....	6	TRIPLE METER .....	28
ILLUMINATION CONTROL .....	7	UNIFIED METER AND A/C AMP. ....	28
SHIFT-UP INDICATOR .....	7	POWER SUPPLY AND GROUND CIRCUIT .....	28
FAIL-SAFE .....	8	VOLTMETER .....	28
Component Parts and Harness Connector Location...	9	OIL PRESSURE GAUGE .....	28
Arrangement of Combination Meter .....	10	TRIP COMPUTER .....	29
Schematic .....	11	FAIL-SAFE .....	31
Wiring Diagram — METER — .....	12	Schematic .....	32
Terminals and Reference Value for Combination Meter .....	14	Wiring Diagram — 3METER — .....	33
Terminals and Reference Value for Unified Meter and A/C Amp. ....	15	Terminals and Reference Value for Triple Meter ...	37
Self-Diagnosis Mode of Combination Meter .....	16	Terminals and Reference Value for Unified Meter and A/C Amp. ....	38
SELF-DIAGNOSIS FUNCTION .....	16	Terminals and Reference Value for Combination Meter .....	39
OPERATION PROCEDURE .....	16	Self-Diagnosis Mode of Triple Meter .....	40
CONSULT-II Function (METER A/C AMP) .....	16	SELF-DIAGNOSIS FUNCTION .....	40
Trouble Diagnosis .....	17	OPERATION PROCEDURE .....	40
HOW TO PERFORM TROUBLE DIAGNOSIS ...	17	CONSULT-II Function (METER A/C AMP) .....	40
PRELIMINARY CHECK .....	17	Trouble Diagnosis .....	41
Symptom Chart .....	17	HOW TO PERFORM TROUBLE DIAGNOSIS ...	41
Power Supply and Ground Circuit Inspection .....	18	PRELIMINARY CHECK .....	41
Vehicle Speed Signal Inspection .....	19	Symptom Chart .....	41
Engine Speed Signal Inspection .....	20	Vehicle Speed Signal Inspection .....	42
Engine Coolant Temperature Signal Inspection ....	20	Fuel Consumption Monitor Signal Inspection .....	42
Fuel Level Sensor Signal Inspection .....	21	Oil Pressure Sensor Signal Inspection .....	42
Illumination Control Switch Inspection .....	22	Trip Computer Switch Inspection .....	44
		Removal and Installation of Triple Meters .....	44

REMOVAL .....	44	<b>WARNING CHIME .....</b>	<b>75</b>
INSTALLATION .....	44	System Description .....	75
Disassembly and Assembly for Triple Meters .....	45	IGNITION KEY WARNING CHIME .....	75
DISASSEMBLY .....	45	LIGHT WARNING CHIME .....	75
ASSEMBLY .....	45	SEAT BELT WARNING CHIME .....	76
<b>UNIFIED METER AND A/C AMP .....</b>	<b>46</b>	Component Parts and Harness Connector Location .....	76
System Description .....	46	Schematic .....	77
DESCRIPTION .....	46	Wiring Diagram — CHIME — .....	78
COMBINATION METER CONTROL FUNCTION .....	46	Terminals and Reference Value for BCM .....	81
TRIPLE METER CONTROL FUNCTION .....	47	Terminals and Reference Value for Unified Meter and A/C Amp. ....	85
A/C AUTO AMP. FUNCTION .....	47	Terminals and Reference Value for Combination Meter .....	85
OTHER FUNCTIONS .....	47	CONSULT-II Function (METER A/C AMP) .....	87
Schematic .....	48	CONSULT-II Function (BCM) .....	87
CONSULT-II Function (METER A/C AMP) .....	49	DIAGNOSTIC ITEMS DESCRIPTION .....	87
CONSULT-II BASIC OPERATION .....	49	CONSULT-II BASIC OPERATION PROCEDURE .....	87
SELF-DIAGNOSTIC RESULTS .....	50		
DATA MONITOR .....	51	DATA MONITOR .....	88
Power Supply and Ground Circuit Inspection .....	53	ACTIVE TEST .....	88
DTC [U1000] CAN Communication Circuit .....	54	SELF-DIAGNOSTIC RESULTS .....	89
DTC [B2201] Triple Meter Communication Circuit .....	54	Trouble Diagnosis .....	89
DTC [B2202] Meter Communication Circuit .....	56	HOW TO PERFORM TROUBLE DIAGNOSIS .....	89
DTC [B2205] Vehicle Speed Circuit .....	59	PRELIMINARY INSPECTION .....	89
Removal and Installation of Unified Meter and A/C Amp. ....	59	Symptom Chart .....	90
REMOVAL .....	59	Power Supply and Ground Circuit Inspection .....	90
INSTALLATION .....	59	Meter Buzzer Circuit Inspection .....	91
<b>WARNING LAMPS .....</b>	<b>60</b>	Driver Side Door Switch Signal Inspection .....	92
System Description .....	60	Key Switch Signal Inspection .....	93
OIL PRESSURE WARNING LAMP .....	60	Lighting Switch Signal Inspection .....	94
Schematic .....	61	Seat Belt Buckle Switch (Driver Side) Signal Inspec- tion .....	95
Wiring Diagram — WARN — .....	62	Component Inspection .....	96
CONSULT-II Function (METER A/C AMP) .....	70	DRIVER SIDE DOOR SWITCH .....	96
Oil Pressure Warning Lamp Stays Off (Ignition Switch ON) or Stays On (Oil Pressure Is Normal) .....	70	SEAT BELT BUCKLE SWITCH (DRIVER SIDE) .....	96
<b>A/T INDICATOR .....</b>	<b>71</b>	KEY SWITCH .....	96
System Description .....	71	<b>CAN COMMUNICATION .....</b>	<b>97</b>
MANUAL MODE .....	71	System Description .....	97
NOT MANUAL MODE .....	71	CAN Communication Unit .....	97
Wiring Diagram — AT/IND — .....	72		
CONSULT-II Function (METER A/C AMP) .....	74		
A/T Indicator Is Malfunction .....	74		

# PRECAUTIONS

## PRECAUTIONS

PFP:00011

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NKS0005P

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### Precautions for Battery Service

NKS0005Q

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

## COMBINATION METERS

PFP:24814

### System Description

NKS0005S

#### UNIFIED METER CONTROL UNIT

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled by the unified meter control unit, which is built into the combination meter. Unified meter control unit receives a signals from unified meter and A/C amp.
- Warning lamp and indicator lamp of combination meter are controlled by signals drawn from the unified meter and A/C amp.
- Odo/trip meter and A/T indicator segments can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.

#### UNIFIED METER AND A/C AMP.

Refer to [DI-46, "COMBINATION METER CONTROL FUNCTION"](#) in "UNIFIED METER AND A/C AMP".

#### POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 24.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to combination meter terminal 23.

With the ignition switch in the ACC or ON position, power is supplied


- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to combination meter terminal 14.

Ground is supplied

- to combination meter terminals 10, 11 and 12
- through body grounds M30 and M66.

#### SPEEDOMETER


- VDC/TCS/ABS control unit [with VDC] or ABS actuator and electric unit (control unit) [without VDC] provides a vehicle speed signal to the unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. converts the vehicle speed signal to the 8-pulse signal, and outputs the vehicle speed signal (8-pulse) to combination meter.
- Combination meter indicates the vehicle speed according to vehicle speed signal (8-pulse).



# COMBINATION METERS


## TACHOMETER

- ECM provides engine speed signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits engine speed signal to combination meter with communication line.
- Combination meter indicates the engine speed according to engine speed signal.



## WATER TEMPERATURE GAUGE

- ECM provides engine coolant temperature signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits engine coolant temperature signal to combination meter with communication line.
- Combination meter indicates the engine coolant temperature according to engine coolant temperature signal.



# COMBINATION METERS

## FUEL GAUGE

- Unified meter and A/C amp. reads a resistor signal from fuel level sensor.

Signal is supplied

- from unified meter and A/C amp. terminal 36
- through fuel level sensor unit and fuel pump (main) terminals 5 and 2, and
- through fuel level sensor unit (sub) terminals 2 and 1
- to unified meter and A/C amp. terminal 28.


- Unified meter and A/C amp. provides a fuel level signal to combination meter with communication line.
- Combination meter indicates the approximate fuel level according to fuel level signal.

## ODO/TRIP METER

- VDC/TCS/ABS control unit [with VDC] or ABS actuator and electric unit (control unit) [without VDC] provides a vehicle speed signal to the unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. converts the vehicle speed signal to the 8-pulse signal, and outputs the vehicle speed signal (8-pulse) to combination meter.
- Combination meter uses the vehicle speed signal (8-pulse) to calculate the mileage, and displays it.

## How to Change The Display

Pressing the odo/trip meter switch toggles the display mode in the following order.



- The odo/trip meter display mode toggling and trip display resetting can be identified by the time elapsed from pressing the odo/trip meter switch to releasing it.
- When resetting with “trip A” displayed, only “trip A” is reset. (The “trip B” functions in the same way.).

## NOTE:

The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.

# COMBINATION METERS

## ILLUMINATION CONTROL

### Daytime Mode


When ignition switch is turned ON, combination meter and triple meter illumination is turned ON by unified meter control unit.

### Nighttime Mode

- Unified meter control unit is transferred to nighttime mode, with ignition switch turned ON and position light request signal from BCM with CAN communication.
- When in nighttime mode, trip computer switch, and illumination control switch illumination turns ON by unified meter control unit. Each illumination is controlled by unified meter control unit.
- Each illumination can be adjusted to 16 step by illumination control switch in nighttime mode.

#### NOTE:

For further details of illumination circuit, refer to [LT-171, "ILLUMINATION"](#).




## SHIFT-UP INDICATOR

- Shift-up indicator can be used when shifting up at a constant engine speed from any gear while driving. It becomes a guide for shift-up timing.
- Shift-up indicator flashes approximately 500 rpm before reaching the engine speed set. It illuminates when reaching the engine speed set.

Shift-up engine speed can be set by the shift-up indicator setting mode on trip computer. Refer to [DI-31, "Shift-up Indicator Setting Mode"](#).

#### NOTE:

- There may be a time lag between the shift-up indicator illumination and the tachometer indication.
- If the battery cable is disconnected, the set engine speed becomes 6,600 rpm.



## COMBINATION METERS

### FAIL-SAFE

Combination meter performs fail-safe operation when unified meter and A/C amp. communication is malfunction.


Function		Fail-safe operation
Speedometer		Return to zero
Tachometer		Reset to zero
Fuel gauge		
Water temperature gauge		
Illumination control	Combination meter illumination	Change to nighttime mode
Odo/trip meter		Integrate in response to 8-pulse input
A/T indicator		The display turns OFF
Meter buzzer		The meter buzzer turns OFF
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns ON
	VDC OFF indicator lamp	
	TCS OFF indicator lamp	
	SLIP indicator lamp	
	Brake warning lamp	
	Tire pressure warning lamp	
	A/T CHECK lamp	The lamp turns OFF
	Oil pressure warning lamp	
	Door warning lamp	
	High beam indicator lamp	
	Turn signal indicator lamp	
	Malfunction indicator lamp	
	CRUISE indicator lamp	
	SET indicator lamp	



# COMBINATION METERS

## Component Parts and Harness Connector Location

NKS0005T



A

B

C

D

E

F

G

H

I

J

DI

L

M



# COMBINATION METERS

NKS0005U

## Arrangement of Combination Meter

### NOTE:

Tachometer red zone for M/T models is 7000 – 8000 r/min.



\* THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.


PKIC3994E

# COMBINATION METERS

## Schematic

NKS0005V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M






TKWT2301E

# COMBINATION METERS

## Wiring Diagram — METER —

NKS0005W

### DI-METER-01



REFER TO THE FOLLOWING.

(E108), (F102), (B1) -SUPER MULTIPLE JUNCTION (SMJ)




(M4), (M5) -FUSE BLOCK-JUNCTION BOX (J/B)

(E51), (E118), (F101) -ELECTRICAL UNITS

TKWT3989E

# COMBINATION METERS

## DI-METER-02



★: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.





REFER TO THE FOLLOWING.  
(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWT3990E

# COMBINATION METERS

## Terminals and Reference Value for Combination Meter




NKS0005X

Terminal No.	Wire color	Item	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
10	B	Ground	ON	—	0 V
11					
12					
14	LG	ACC power supply	ACC	—	Battery voltage
18	R/Y	Illumination signal	ON	Lighting switch ON, then operate the illumination control switch.	<p>&lt;e.g.&gt;When brightness level is midway</p>  <p>PKIA3771E</p>
				Lighting switch OFF	0 V
20	W	Vehicle speed signal input (8-pulse)	ON	Speedometer operated. [When vehicle speed is approx. 40 km/h (25 MPH)]	<p><b>NOTE:</b> Maximum voltage may be 5 V due to specifications (connected units).</p>  <p>PKIA1935E</p>
21	R/G	TX communication line (To unified meter and A/C amp.)	ON	—	 <p>SKIA3361E</p>
22	L/OR	RX communication line (From unified meter and A/C amp.)	ON	—	 <p>SKIA3362E</p>
23	G/Y	Ignition power supply	ON	—	Battery voltage
24	R/W	Battery power supply	OFF	—	Battery voltage

# COMBINATION METERS

## Terminals and Reference Value for Unified Meter and A/C Amp.

NKS0005Y

Terminal No.	Wire color	Item	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
1	L	CAN-H	—	—	—
9	L/OR	TX communication line (To combination meter)	ON	—	
11	P	CAN-L	—	—	—
19	R/G	RX communication line (From combination meter)	ON	—	
21	R/W	Battery power supply	OFF	—	Battery voltage
22	Y/G	Ignition power supply	ON	—	Battery voltage
26	W	Vehicle speed signal output (8-pulse)	ON	Speedometer operated. [When vehicle speed is approx. 40 km/h (25 MPH)]	<p><b>NOTE:</b> Maximum voltage may be 5 V due to specifications (connected units).</p> 
28	W/B	Fuel level sensor signal	—	—	Refer to <a href="#">DI-25, "FUEL LEVEL SENSOR UNIT"</a> .
29	B	Ground (For power)	ON	—	0 V
30	B	Ground	ON	—	0 V
36	R/B	Fuel level sensor ground	ON	—	0 V
46	L/W	ACC power supply	ACC	—	Battery voltage

## COMBINATION METERS

### Self-Diagnosis Mode of Combination Meter SELF-DIAGNOSIS FUNCTION

NKS0005Z

- Odo/trip meter segment and A/T indicator segment operation can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.


#### OPERATION PROCEDURE

1. Turn ignition switch ON, and switch the odo/trip meter to “trip A” or “trip B”.

**NOTE:**

If the diagnosis function is activated with “trip A” displayed, the mileage on “trip A” will indicate “0000.0”, but the actual trip mileage will be retained. (The “trip B” functions in the same way.)

2. Turn ignition switch OFF.
3. While pressing the odo/trip meter switch, turn ignition switch ON again.
4. Make sure that the trip meter displays “0000.0”.
5. Press the odo/trip meter switch at least 3 times (within 7 seconds after the ignition switch is turned ON).
6. All the segments on the odo/trip meter and A/T indicator illuminate, and simultaneously the low-fuel warning lamp indicator illuminates. At this time, the unified meter control unit is turned to diagnosis mode.




**NOTE:**

- Check combination meter power supply and ground circuit when self-diagnosis mode of combination meter does not start. Replace combination meter if normal.
  - If any of the segments is not displayed, replace combination meter.
7. Press the odo/trip meter switch. Each meter/gauge should indicate as shown in the figure while pressing odo/trip meter switch. (At this time, the low-fuel warning lamp goes off).

**NOTE:**

If any of the meter/gauge is not activated, replace combination meter.



### CONSULT-II Function (METER A/C AMP)

NKS00060

Refer to [DI-49, "CONSULT-II Function \(METER A/C AMP\)"](#) in “UNIFIED METER AND A/C AMP”.



# COMBINATION METERS

## Trouble Diagnosis

NKS00061

### HOW TO PERFORM TROUBLE DIAGNOSIS

1. Confirm the symptom or customer complaint.
2. Perform preliminary check. Refer to [DI-17, "PRELIMINARY CHECK"](#).
3. According to the symptom chart, make sure of the symptom cause and repair or replace applicable parts.
4. Does the meter operate normally? If so, GO TO 5. If not, GO TO 2.
5. INSPECTION END

### PRELIMINARY CHECK

#### 1. CHECK OPERATION OF SELF-DIAGNOSIS MODE (COMBINATION METER)

Perform self-diagnosis mode of combination meter. Refer to [DI-16, "SELF-DIAGNOSIS FUNCTION"](#).

Does self-diagnosis mode operation normally?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK UNIFIED METER AND A/C AMP. (CONSULT-II)

Perform self-diagnosis of unified meter and A/C amp. Refer to [DI-40, "CONSULT-II Function \(METER A/C AMP\)"](#).

Self-diagnostic results

- No malfunction detected >> INSPECTION END  
Malfunction detected >> Check applicable parts, and repair or replace corresponding parts.

#### 3. CHECK POWER SUPPLY AND GROUND CIRCUIT OF COMBINATION METER

Check power supply and ground circuit of combination meter. Refer to [DI-18, "Power Supply and Ground Circuit Inspection"](#).

OK or NG

- OK >> Replace combination meter.  
NG >> Repair power supply and ground circuit of combination meter.

## Symptom Chart

NKS00062

Symptom	Possible cause
Speedometer and odometer/trip meter indication is malfunction.	Refer to <a href="#">DI-19, "Vehicle Speed Signal Inspection"</a> .
Tachometer indication is malfunction.	Refer to <a href="#">DI-20, "Engine Speed Signal Inspection"</a> .
Water temperature gauge indication is malfunction.	Refer to <a href="#">DI-20, "Engine Coolant Temperature Signal Inspection"</a> .
Fuel gauge indication is malfunction.	Refer to <a href="#">DI-21, "Fuel Level Sensor Signal Inspection"</a> .
Low-fuel warning lamp indication is irregular.	
A/T position indicator is malfunction.	Refer to <a href="#">DI-74, "A/T Indicator Is Malfunction"</a> .
Illumination control does not operate.	Refer to <a href="#">DI-22, "Illumination Control Switch Inspection"</a> .

# COMBINATION METERS

## Power Supply and Ground Circuit Inspection

NKS00064

### 1. CHECK FUSE

Check for blown combination meter fuses.

Power source	Fuse No.
Battery	19
Ignition switch ACC or ON	6
Ignition switch ON or START	14

OK or NG


OK >> GO TO 2.

NG >> Be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

### 2. CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector M19 terminals 24, 23, 14 and ground.

Terminals		Ignition switch position			
(+)		(-)			
Connector	Terminal (Wire color)		OFF	ACC	ON
M19	24	Ground	Battery voltage	Battery voltage	Battery voltage
	23		0 V	0 V	Battery voltage
	14		0 V	Battery voltage	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Repair harness between combination meter and fuse.

### 3. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M19 terminals 10, 11, 12 and ground.

10 – Ground

11 – Ground

12 – Ground

: Continuity should exist.



OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.

# COMBINATION METERS

## Vehicle Speed Signal Inspection

NKS00065

Symptom: Indication is irregular for the Speedometer and odo/trip meter.

### 1. CHECK VDC/TCS/ABS CONTROL UNIT OR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform the following units self-diagnosis.

- VDC/TCS/ABS control unit [with VDC]. Refer to [BRC-100, "CONSULT-II Functions \(VDC/TCS/ABS\)"](#).
- ABS actuator and electric unit (control unit) [without VDC (with TCS)]. Refer to [BRC-55, "CONSULT-II Functions \(TCS/ABS\)"](#).
- ABS actuator and electric unit (control unit) [without VDC (without TCS)]. Refer to [BRC-19, "CONSULT-II Functions \(ABS\)"](#).

#### Self-diagnostic results

No malfunction detected >> GO TO 2.



Malfunction detected >> Check applicable parts, and repair or replace corresponding parts.

### 2. CHECK UNIFIED METER AND A/C AMP. OUTPUT SIGNAL

1. Start engine and drive vehicle at approximately 40 km/h (25 MPH).
2. Check voltage signal between unified meter and A/C amp. harness connector M49 terminal 26 and ground.

**NOTE:**  
Maximum voltage may be 5 V due to specifications (connected units).

26 – Ground:



#### OK or NG

OK >> GO TO 3.

NG >> • If monitor indicates "0 V" constantly, repair or replace malfunctioning parts after checking each unit inputting vehicle speed signal (8 pulse), harness and connector between each unit and unified meter and A/C amp.

- If monitor indicates "5 V" or "12 V" constantly, replace unified meter and A/C amp.

### 3. CHECK CONTINUITY BETWEEN COMBINATION METER AND UNIFIED METER AND A/C AMP.


1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector M19 terminal 20 and unified meter and A/C amp. harness connector M49 terminal 26.

20 – 26 : Continuity should exist.

#### OK or NG

OK >> Replace combination meter.

NG >> Repair harness or connector.



# COMBINATION METERS

## Engine Speed Signal Inspection

NKS00066

Symptom: Tachometer indication is malfunction.

### 1. CHECK UNIFIED METER AND A/C AMP. OUTPUT SIGNAL

1. Start engine and select "METER A/C AMP" on CONSULT-II.
2. Using "TACHO METER" on "DATA MONITOR", compare the value of "DATA MONITOR" with tachometer pointer of combination meter.

OK or NG

- OK >> GO TO 2.  
NG >> Replace combination meter.

DATA MONITOR	
MONITOR	
TACHO METER	XXXX rpm

PKIA2090E

### 2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Select "ENGINE" on CONSULT-II.
2. Using "ENG SPEED" on "DATA MONITOR", print out the CONSULT-II screen when the engine is idling.
3. Select "METER A/C AMP" on CONSULT-II.
4. Using "TACHO METER" on "DATA MONITOR", compare the value of "DATA MONITOR" of the idling speed with that of the "ENG SPEED".

OK or NG

- OK >> Perform ECM self-diagnosis. Refer to [EC-122, "CONSULT-II Function \(ENGINE\)"](#).  
NG >> Replace unified meter and A/C amp.

DATA MONITOR	
MONITOR	
ENG SPEED	XXX rpm

SKIA4367E

## Engine Coolant Temperature Signal Inspection

NKS00067

Symptom: Water temperature gauge indication is malfunction.

### 1. CHECK UNIFIED METER AND A/C AMP. OUTPUT SIGNAL

1. Start engine and select "METER A/C AMP" on CONSULT-II.
2. Using "W TEMP METER" on the "DATA MONITOR", compare the value of "DATA MONITOR" with water temperature gauge pointer of combination meter.

Water temperature gauge pointer	Reference value of data monitor [°C (°F)]
Hot	Approx. 130 (266)
Middle	Approx. 70 - 105 (158 - 221)
Cold	Approx. 50 (122)

OK or NG

- OK >> GO TO 2.  
NG >> Replace combination meter.

DATA MONITOR	
MONITOR	
W TEMP METER	XX °C

PKIA2091E


# COMBINATION METERS

## 2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Select "ENGINE" on CONSULT-II.
2. Using "COOLAN TEMP/S" on "DATA MONITOR", print out the CONSULT-II screen.
3. Select "METER A/C AMP" on CONSULT-II.
4. Using "W TEMP METER" on, compare the value of "DATA MONITOR" with that of the "COOLAN TEMP/S".

### OK or NG

- OK >> Perform ECM self-diagnosis. Refer to [EC-122, "CONSULT-II Function \(ENGINE\)"](#).
- NG >> Replace unified meter and A/C amp.



NKS00068

## Fuel Level Sensor Signal Inspection

Symptom:

- Fuel gauge indication is malfunction.
- Low-fuel warning lamp indication is irregular.

### NOTE:

The following symptoms are not malfunction.

Fuel level sensor unit

- Depending on vehicle position or driving circumstance, the fuel level in the tank varies, and the pointer may fluctuate.
- If the vehicle is fueled with the ignition switch ON, the pointer will move slowly.


Low-fuel warning lamp

- Depending on vehicle position or driving circumstance, the fuel in the tank flows and the warning lamp ON timing may change.

## 1. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Select "METER A/C AMP" on CONSULT-II.
2. Using "FUEL METER" on "DATA MONITOR", compare the value of "DATA MONITOR" with fuel gauge pointer of combination meter.

Fuel gauge indication	Value on monitor [lit.]
Full	Approx. 74
Three quarters	Approx. 61
Half	Approx. 42
A quarter	Approx. 22
Empty	Approx. 8



### OK or NG

- OK >> GO TO 2.
- NG >> Replace combination meter.

## 2. CHECK FUEL LEVEL SENSOR

1. Turn ignition switch OFF.
2. Check components. Refer to [DI-25, "FUEL LEVEL SENSOR UNIT"](#).

### OK or NG

- OK >> GO TO 3.
- NG >> Replace fuel level sensor unit.

## COMBINATION METERS

### 3. CHECK FUEL LEVEL SENSOR (SUB) CIRCUIT

1. Disconnect unified meter and A/C amp. connector and fuel level sensor unit (sub) connector.
2. Check continuity between unified meter and A/C amp. harness connector M49 terminal 28 and fuel level sensor unit (sub) harness connector B28 terminal 1.

**28 – 1 : Continuity should exist.**


3. Check continuity between unified meter and A/C amp. harness connector M49 terminal 28 (W/B) and ground.

**28 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



### 4. CHECK FUEL LEVEL SENSOR (MAIN-SUB) CIRCUIT

1. Disconnect fuel level sensor unit and fuel pump (main) connector.
2. Check continuity between fuel level sensor unit (sub) harness connector B28 terminal 2 and fuel level sensor unit and fuel pump (main) harness connector B27 terminal 2.

**2 – 2 : Continuity should exist.**


3. Check continuity between fuel level sensor unit (sub) harness connector B28 terminal 2 and ground.

**2 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



### 5. CHECK FUEL LEVEL SENSOR (MAIN) CIRCUIT

1. Check continuity between fuel level sensor unit and fuel pump (main) harness connector B27 terminal 5 and unified meter and A/C amp. harness connector M49 terminal 36.

**5 – 36 : Continuity should exist.**


2. Check continuity between fuel level sensor unit and fuel pump (main) harness connector B27 terminal 5 and ground.

**5 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness or connector.



### 6. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any of the internal components in the fuel tank.

OK or NG

OK >> Replace unified meter and A/C amp.

NG >> Install the fuel level sensor unit properly.

### Illumination Control Switch Inspection

Symptom: Illumination control does not operate.

NKS00069

# COMBINATION METERS

## 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Remove combination meter.
3. Remove rear finisher of combination meter.
4. Check illumination control switch connector for looseness.

OK or NG

- OK >> GO TO 2.  
NG >> Repair illumination control switch connector.


## 2. CHECK ILLUMINATION CONTROL SWITCH

1. Disconnect illumination control switch connector.
2. Check continuity between illumination control switch harness connector M207 terminals 3 or 4 and 5.

Terminal		Condition	Continuity
3	5	Illumination control switch upper side (BRIGHTEN) is pressed.	Yes
		Illumination control switch upper side (BRIGHTEN) is released.	No
4		Illumination control switch lower side (DARKEN) is pressed.	Yes
		Illumination control switch lower side (DARKEN) is released.	No

OK or NG

- OK >> Replace combination meter.  
NG >> Replace illumination control switch.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# COMBINATION METERS

---

## Fuel Gauge Pointer Fluctuates, Indicator Wrong Value or Varies

NKS0006A

### 1. CHECK FUEL GAUGE FLUCTUATION

---

Test drive vehicle to see if gauge fluctuates only during driving or at the instant of stopping.

Does the indication value vary only during driving or at the instant of stopping?

- YES >> The pointer fluctuation may be caused by fuel level change in the fuel tank. Condition is normal.
- NO >> Ask the customer about the situation when the symptom occurs in detail, and perform the trouble diagnosis.

## Fuel Gauge Does Not Move to FULL Position

NKS0006B

### 1. QUESTION 1

---

Does it take a long time for the pointer to move to FULL position?

- YES >> GO TO 2.
- NO >> GO TO 3.

### 2. QUESTION 2

---

Was the vehicle fueled with the ignition switch ON?

- YES >> Be sure to fuel the vehicle with the ignition switch OFF. Otherwise, it will take a long time to move to FULL position because of the characteristic of the fuel gauge.
- NO >> GO TO 3.

### 3. QUESTION 3

---

Is the vehicle parked on an incline?

- YES >> Check the fuel level indication with vehicle on a level surface.
- NO >> GO TO 4.

### 4. QUESTION 4

---

During driving, does the fuel gauge pointer move gradually toward EMPTY position?

- YES >> Check the fuel level sensor unit. Refer to [DI-25, "FUEL LEVEL SENSOR UNIT"](#).
- NO >> The float arm may interfere or bind with any of the components in the fuel tank.



# COMBINATION METERS

## Electrical Components Inspection FUEL LEVEL SENSOR UNIT

NKS0006C

For removal, refer to [FL-4, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY"](#).


### Fuel Level Sensor Unit and Fuel Pump (Main)

Check the resistance between terminals 2 and 5.

Terminal		Float position [mm (in)]		Resistance value [ $\Omega$ ]
2	5	*1	Empty	30 (1.18)
		*2	Full	210 (8.27)

\*1 and \*2: When float rod is in contact with stopper.

- If the results of check are NG, check the fuel level sensor unit and fuel pump (main) harness. Refer to [DI-25, "Fuel Level Sensor Unit and Pump \(Main\) Harness"](#).




### Fuel Level Sensor Unit and Pump (Main) Harness

Check the continuity between the following terminals.

Terminal	Continuity
2 - Signal terminal	Yes
5 - Ground terminal	

- If the results of check are NG, replace fuel pump assembly. If the results of check are OK, replace fuel level sensor unit.




### Fuel Level Sensor Unit (Sub)

Check the resistance between terminals 1 and 2.

Terminal		Float position [mm (in)]		Resistance value [ $\Omega$ ]
1	2	*1	Full	8 (0.31)
		*2	Empty	175 (6.89)

\*1 and \*2: When float rod is in contact with stopper.




# COMBINATION METERS

## Removal and Installation for Combination Meter REMOVAL

NKS0006D

1. Remove instrument driver panel lower. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove steering column lower cover. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
3. Remove bolts (4) and remove column upper cover and combination meter assembly. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
4. Remove screws (6) and remove combination meter.




## INSTALLATION

Installation is the reverse order of removal.

## Disassembly and Assembly for Combination Meter

NKS0006E

SEC.248



PKIA1761E


- |                                 |                                |                               |
|---------------------------------|--------------------------------|-------------------------------|
| 1. Front finisher               | 2. Front cover                 | 3. Unified meter control unit |
| 4. Rear cover                   | 5. Screws                      | 6. Rear finisher              |
| 7. Upper cover                  | 8. Illumination control switch | 9. Trip computer switch       |
| 10. Steering column upper cover |                                |                               |

## DISASSEMBLY


1. Remove screws (6) to separate steering column upper cover.
2. Disengage tabs (2) to separate front finisher.
3. Disengage tabs (8) to separate rear finisher.

## COMBINATION METERS

4. Disconnect illumination control switch connector and trip computer switch connector.



5. Remove screws (2) and remove rear cover.



6. Disengage tabs (4) to separate upper cover from rear cover.
7. Remove illumination control switch.
8. Remove trip computer switch.
9. Disengage tabs (7) to separate front cover.

### ASSEMBLY

Assembly is the reverse order of disassembly.

# TRIPLE METERS


## TRIPLE METERS

PFP:24845

### System Description TRIPLE METER

NKS0006F

- Oil pressure gauge and voltmeter are controlled by the triple meter.
- Trip computer is controlled by the signals from the unified meter and A/C amp.
- Triple meter operation can be checked with self-diagnosis mode of combination meter.



### UNIFIED METER AND A/C AMP.

Refer to [DI-47, "TRIPLE METER CONTROL FUNCTION"](#) in "UNIFIED METER AND A/C AMP".

### POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [No. 19, located in the fuse block (J/B)]
- to triple meter terminal 2.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to triple meter terminal 3.

Ground is supplied

- to triple meter terminal 1
- through grounds M30 and M66.

### VOLTMETER

When ignition switch is turned to the ON position, the voltmeter indicates the battery voltage.

### OIL PRESSURE GAUGE

With the ignition switch in the ON or START position, power is supplied

- through triple meter terminal 9
- to oil pressure sensor terminal 1.

Ground is supplied

- to triple meter terminal 7
- through oil pressure sensor terminal 3.

And triple meter reads oil pressure signal from oil pressure sensor

- from oil pressure sensor terminal 2
- to triple meter terminal 8.

### NOTE:

- Triple meter judges an oil pressure condition by oil pressure signal, and transmits oil pressure warning lamp signal to combination meter through unified meter and A/C amp. with communication line.
- Oil pressure gauge is not designed to indicate the low oil level. Use the oil level gauge to check the oil level.

# TRIPLE METERS

## TRIP COMPUTER


### Function

When the ignition switch is turned ON, the display scrolls all the modes. And then shows the mode chosen before the ignition switch is turned OFF.

- Trip computer is operated by the trip computer switch.
- Trip computer receives a switch signal from combination meter through the unified meter and A/C amp. with communication line.

The mode of the trip computer is the following.

- Vehicle speed
- Ambient air temperature
- DTE (distance to empty)
- Average fuel consumption
- Average vehicle speed
- Trip time
- Trip distance
- Stopwatch
- Tire pressure
- Shift-up indicator setting mode



### How to Change/ Reset the Displayed Mode

- The displayed mode can be selected in the following order by momentarily pressing the trip computer mode switch.
  - Vehicle speed → Ambient air temperature → DTE → Average fuel consumption and average vehicle speed → Trip time and trip distance → Stopwatch → Tire pressure → Shift-up indicator setting
- Holding the trip computer setting switch for more than 1 second resets the displayed mode (Average fuel consumption, average vehicle speed, trip time, trip distance or stopwatch).

### NOTE:

When the ambient air temperature warning, the tire pressure warning, and the DTE warning, match warning conditions at the same time, the display automatically displays the ambient air temperature warning.

### Vehicle Speed

- Trip computer receives vehicle speed signal from combination meter through the unified meter and A/C amp. with communication line.
- Trip computer displays the vehicle speed according to vehicle speed signal.

### Ambient Air Temperature

- Unified meter and A/C amp. reads ambient air temperature signal from ambient air temperature sensor. Signal is supplied
  - from unified meter and A/C amp. terminal 39
  - through ambient sensor terminal 1 and 2
  - to unified meter and A/C amp. terminal 49.
- Trip computer receives ambient air temperature signal from the unified meter and A/C amp. with communication line.
- Trip computer displays ambient air temperature according to ambient air temperature signal.

### NOTE:

- Indication range is between  $-30$  and  $55$  °C ( $-22$  and  $131$  °F).
- When ambient air temperature is less than  $-30$  °C ( $-22$  °F) or more than  $55$  °C ( $131$  °F), the display shows "--".
- When ambient air temperature is less than  $3$  °C ( $37$  °F) continuously, the display shows "ICY" as warning. At more than  $4$  °C ( $39$  °F) the display stops showing "ICY".

# TRIPLE METERS

---

## DTE (Distance to Empty)

- Unified meter and A/C amp. uses following signals to calculate the DTE signal.
  - Fuel remaining signal (from the fuel level sensor unit)
  - Fuel consumption signal (from ECM)
  - Vehicle speed signal [from VDC/TCS/ABS control unit or ABS actuator and electric unit (control unit)]
- Trip computer receives DTE signal from the unified meter and A/C amp. with communication line.
- Trip computer displays the DTE according to DTE signal.
- The indication is refreshed every 30 seconds.

### NOTE:

- When fuel remaining is less than approx. 10 ℓ (10-5/8 US qt, 8-3/4 Imp qt), the display shows “dte” blink as a warning. And the fuel remaining is less than approx. 8 ℓ (8-1/2 US qt, 7 Imp qt), the display shows “---”.
- When the battery cable is disconnected and reconnected, the display shows “----” for 30 seconds.

## Average Fuel Consumption

- Unified meter and A/C amp. uses following signals to calculate the average fuel consumption signal.
  - Fuel consumption signal (from ECM)
  - Vehicle speed signal [from VDC/TCS/ABS control unit or ABS actuator and electric unit (control unit)]
- Trip computer receives the average fuel consumption signal from the unified meter and A/C amp. with communication line.
- Trip computer displays the average fuel consumption according to the average fuel consumption signal.
- The indication is refreshed every 30 seconds.

### NOTE:

If the average fuel consumption is reset, the average vehicle speed is reset at the same time. While driving about 1/3 miles (500 m) or for 80 seconds after resetting, the display shows “----”.

## Average Vehicle Speed

- Unified meter and A/C amp. uses following signals to calculate the average vehicle speed signal.
  - Trip distance signal
  - Trip time signal
- Trip computer receives the average vehicle speed signal from the unified meter and A/C amp. with communication line.
- Trip computer displays the average vehicle speed according the average vehicle speed signal.
- The indication shows refreshed every 30 seconds.

### NOTE:

If the average vehicle speed is reset, the average fuel consumption will be reset at the same time. After resetting, the display will show “----” for 30 seconds.

## Trip Time

- Unified meter and A/C amp. calculates the time during ignition switch ON.
- Trip computer receives the trip time signal from the unified meter and A/C amp. with communication line.
- Trip computer displays trip time according to the trip time signal

### NOTE:

If trip time is reset, trip distance is reset at the same time.

## Trip Distance

- Unified meter and A/C amp. uses following signals to calculate the average fuel consumption signal.
  - Trip time signal
  - Vehicle speed signal from VDC/TCS/ABS control unit or ABS actuator and electric unit (control unit)
- Trip computer receives the trip distance signal from the unified meter and A/C amp. with communication line.
- Trip computer displays the trip distance according to the trip distance signal.

### NOTE:

If trip distance is reset, trip time will be reset at the same time.

# TRIPLE METERS

## Stopwatch

Trip computer displays stopwatch.

### NOTE:

- After 100 hours, the time will start from the reset display again.
- Even if the display is switched to the other mode while the time is starting, the stopwatch continues to advance until the time in the stopwatch mode is stopped.
- When the ignition switch is turned OFF, the stopwatch is reset.

## Tire Pressure

The tire pressure shows tire pressure 0 - 51 psi (0 - 353 kPa, 0 - 3.6 kg/cm<sup>2</sup>) of all wheels.

- Unified meter and A/C amp. receives tire pressure signals from BCM with CAN communication.
- Trip computer receives tire pressure from the unified meter and A/C amp. with communication line.
- Trip computer displays tire pressure according to tire pressure signal.

### NOTE:

- If the tire pressure signal cannot be received correctly, the display shows "----".
- If the vehicle is being driven with very low tire pressure or a flat tire, the tire pressure mode is automatically selected and "PSI" blinks as warning. It continues blinking until the tire pressure is properly adjusted.

## Shift-up Indicator Setting Mode

Trip computer setting switch	Press and hold (for more than 1 sec.)	Press (for less than 1 sec.)
Setting engine speed	Increase setting engine speed by 500 rpm.	Increase setting engine speed by 100 rpm.

### NOTE:

The range of engine speed is 2,000 - 8,000 rpm (when exceeding 8,000 rpm returns to 2,000 rpm).

## FAIL-SAFE

Triple meter performs fail-safe operation when unified meter and A/C amp. communication is malfunctioning.

Function		Fail-safe operation
Trip computer	Vehicle speed indication	Displays "---"
	Outside air temperature indication	Displays "--"
	DTE (Distance to empty) indication	Displays "----"
	Average fuel consumption indication	
	Average vehicle speed indication	
	Trip distance indication	
	Tire pressure indication	Displays "--:--"
	Trip time indication	
Illumination control	Triple meter illumination	Change to nighttime mode.

## Revision: 2005 August








# TRIPLE METERS

## Wiring Diagram — 3METER —

NKS0006H

### DI-3METER-01






REFER TO THE FOLLOWING.  
 (E108), (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M4), (M5) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWT3991E

# TRIPLE METERS

## DI-3METER-02



REFER TO THE FOLLOWING.







(E108), (F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M90), (E51), (E118), (F101) -ELECTRICAL UNITS

TKWT2304E

# TRIPLE METERS

## DI-3METER-03



REFER TO THE FOLLOWING.



(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWT0499E

# TRIPLE METERS

DI-3METER-04






★: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWB1893E

# TRIPLE METERS

## Terminals and Reference Value for Triple Meter






NKS0006I

Terminal No.	Wire color	Item	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
1	B	Ground	ON	—	0 V
2	R/W	Battery power supply	OFF	—	Battery voltage
3	G/Y	Ignition power supply	ON	—	Battery voltage
4	P	TX communication line (To unified meter and A/C amp.)	ON	—	 <p>SKIA3364E</p>
5	L/B	RX communication line (From unified meter and A/C amp.)	ON	—	 <p>SKIA3363E</p>
7	G/OR	Oil pressure sensor ground	ON	—	0 V
8	LG/R	Oil pressure sensor signal	ON	When ignition switch is in ON position (Engine stopped.)	1 V
				Engine running [When the oil pressure is 80 psi (500 kPa)]	3 V
9	R/L	Oil pressure sensor power supply	ON	—	5 V
12	R	Illumination signal input	ON	Lighting switch ON, then operate the illumination control switch.	<p>&lt;e.g.&gt; When brightness level is midway</p>  <p>SKIA7256E</p>
				Lighting switch OFF	0 V

# TRIPLE METERS

## Terminals and Reference Value for Unified Meter and A/C Amp.

NKS0006K





Terminal No.	Wire color	Item	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
1	L	CAN-H	—	—	—
9	L/OR	TX communication line (To combination meter)	ON	—	 <p>SKIA3362E</p>
10	L/B	TX communication line (To triple meter)	ON	—	 <p>SKIA3363E</p>
11	P	CAN-L	—	—	—
19	R/G	RX communication line (From combination meter)	ON	—	 <p>SKIA3361E</p>
20	P	RX communication line (From triple meter)	ON	—	 <p>SKIA3364E</p>
21	R/W	Battery power supply	OFF	—	Battery voltage
22	Y/G	Ignition power supply	ON	—	Battery voltage
26	W	Vehicle speed signal output (8-pulse)	ON	Speedometer operated. [When vehicle speed is approx. 40 km/h (25 MPH)]	<p><b>NOTE:</b> Maximum voltage may be 5 V due to specifications (connected units).</p>  <p>PKIA1935E</p>
28	W/B	Fuel level sensor signal	—	—	Refer to <a href="#">DI-25, "FUEL LEVEL SENSOR UNIT"</a> .
29	B	Ground (For power)	ON	—	0 V
30	B	Ground	ON	—	0 V
36	R/B	Fuel level sensor ground	ON	—	0 V
39	Y	Ambient sensor signal	—	—	Refer to <a href="#">ATC-95, "Ambient Sensor Circuit"</a> .

# TRIPLE METERS

Terminal No.	Wire color	Item	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
46	L/W	ACC power supply	ACC	—	Battery voltage
49	W/L	Ambient sensor ground	ON	—	Approx. 0 V

## Terminals and Reference Value for Combination Meter

NKS0006J

Terminal No.	Wire color	Item	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
10	B	Ground	ON	—	0 V
11					
12					
19	R	Illumination signal output	ON	Lighting switch ON, then operate the illumination control switch.	<p>&lt;e.g.&gt; When brightness level is midway</p>  <p>SKIA7256E</p>
				Lighting switch OFF	0 V
20	W	Vehicle speed signal input (8-pulse)	ON	Speedometer operated. [When vehicle speed is approx. 40 km/h (25 MPH)]	<p><b>NOTE:</b> Maximum voltage may be 5 V due to specifications (connected units).</p>  <p>PKIA1935E</p>
21	R/G	TX communication line (To unified meter and A/C amp.)	ON	—	 <p>SKIA3361E</p>
22	L/OR	RX communication line (From unified meter and A/C amp.)	ON	—	 <p>SKIA3362E</p>
23	G/Y	Ignition power supply	ON	—	Battery voltage
24	R/W	Battery power supply	OFF	—	Battery voltage

## TRIPLE METERS

### Self-Diagnosis Mode of Triple Meter



NKS0006L

#### SELF-DIAGNOSIS FUNCTION

Triple meter operation can be checked with self-diagnosis mode of combination meter.

#### OPERATION PROCEDURE

1. While pressing the odometer/trip meter switch, turn ignition switch ON.
2. Make sure that the trip meter displays "0000.0".
3. Press the odometer/trip meter switch at least 3 times (within 7 seconds after the ignition switch is turned ON).
4. All the segments on the trip computer illuminate. At this time, the triple meter is turned to self-diagnosis mode.

For USA	For Canada
 <p>88:8.8 h:m:s 88:8.8 mpg 88:8.8 av. 88:8.8 mph 88:8.8 mls ◀ ICYrpm dte PSI</p>	 <p>88:8.8 h:m:s 88:8.8 l/100km 88:8.8 av. 88:8.8 km/h 88:8.8 ◀ ICYrpm dte PSI</p>

SKIA8981E


#### NOTE:

If any of the segments is not displayed, replace triple meter.

5. Press the odometer/trip meter switch. voltmeter and oil pressure gauge should indicate as shown in the figure while pressing odometer/trip meter switch.

#### NOTE:

If voltmeter or oil pressure gauge is not activated, replace triple meter.



### CONSULT-II Function (METER A/C AMP)

NKS0006M

Refer to [DI-49, "CONSULT-II Function \(METER A/C AMP\)"](#) in "UNIFIED METER AND A/C AMP".



# TRIPLE METERS

## Trouble Diagnosis

NKS0006N

### HOW TO PERFORM TROUBLE DIAGNOSIS

1. Confirm the symptom or customer complaint.
2. Perform diagnosis according to diagnosis flow. Refer to [DI-41, "PRELIMINARY CHECK"](#).
3. According to the symptom chart, repair or replace the cause of the symptom.
4. Does the meter operate normally? If so, GO TO 5. If not, GO TO 2.
5. INSPECTION END

### PRELIMINARY CHECK

#### 1. CHECK COMMUNICATION LINE

Perform self-diagnosis of unified meter and A/C amp.

##### Self-diagnostic results content

No malfunction detected>>GO TO 2.

Malfunction detected>>Check applicable parts, and repair or replace corresponding parts.

#### 2. CHECK OPERATION OF SELF-DIAGNOSIS MODE (COMBINATION METER)

Activate self-diagnosis mode of combination meter. Refer to [DI-16, "Self-Diagnosis Mode of Combination Meter"](#).

##### Does self-diagnosis mode operate?

YES >> GO TO 3.

NO >> Check combination meter power supply and ground circuit. If normal, replace combination meter.

#### 3. CHECK OPERATION OF SELF-DIAGNOSIS MODE (TRIPLE METER)

Check operation of triple meter in self-diagnosis mode. Refer to [DI-40, "Self-Diagnosis Mode of Triple Meter"](#).

##### Does self-diagnosis mode operation namely?

YES >> INSPECTION END

NO >> GO TO 3.

#### 4. CHECK POWER SUPPLY AND GROUND CIRCUIT OF TRIPLE METER

Check power supply and ground circuit of triple meter.

##### OK or NG

OK >> Replace triple meter.

NG >> Repair power supply and ground circuit of triple meter.

## Symptom Chart

NKS0006O

Trouble phenomenon	Possible cause
Speed indication is not displayed properly.	Refer to <a href="#">DI-42, "Vehicle Speed Signal Inspection"</a> .
Ambient air temperature indication is not displayed properly. (It may take a short time to steady the indication after ignition switch is turned ON.)  <b>NOTE:</b> If the meter is powered up with the ambient sensor disconnected, ambient air temperature display will show "---" even if the sensor is reconnected. In this case, with the sensor connected, disconnect and reconnect the battery, then the correct temperature will be displayed.	Refer to <a href="#">ATC-95, "AMBIENT TEMPERATURE INPUT PROCESS"</a> in "ATC".
DTE (distance to empty) indication is not displayed properly.	Refer to <a href="#">DI-42, "Fuel Consumption Monitor Signal Inspection"</a> .
Average fuel consumption indication is not displayed properly.	
Shift-up indicator setting indication is not displayed properly or shift-up indicator does not operate properly.	Refer to <a href="#">DI-44, "Trip Computer Switch Inspection"</a> .

# TRIPLE METERS

Trouble phenomenon	Possible cause
Average vehicle speed indication is not indicated properly.	Replace triple meter.
Trip distance indication is not indicated properly.	
Trip time indication is not indicated properly.	
Stopwatch indication is not displayed properly.	
Indication is malfunction of voltmeter.	
Indication is malfunction of oil pressure gauge.	Refer to <a href="#">DI-42, "Oil Pressure Sensor Signal Inspection"</a> .
Trip computer switch is not operate.	Refer to <a href="#">DI-44, "Trip Computer Switch Inspection"</a> .

## Vehicle Speed Signal Inspection

NKS0006R


Symptom: Speed indication is not displayed properly.

### 1. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Start engine and select "METER A/C AMP" on CONSULT-II.
2. Using "SPEED METER" on the "DATA MONITOR", compare the value of data monitor with speed indication of trip computer.

OK or NG

- OK >> Refer to [DI-19, "Vehicle Speed Signal Inspection"](#) of "COMBINATION METERS".
- NG >> Replace triple meter.



PKIA2092E

## Fuel Consumption Monitor Signal Inspection

NKS0006S

Symptom:

- DTE (distance to empty) indication is not displayed properly.
- Average fuel consumption indication is not displayed properly.

### 1. CHECK ECM (CONSULT-II)

Perform self-diagnosis of ECM. Refer to [EC-122, "CONSULT-II Function \(ENGINE\)"](#) .

Self-diagnostic results

No malfunction detected>>Replace unified meter and A/C amp.

Malfunction detected>>Check applicable parts, and repair or replace corresponding parts.

## Oil Pressure Sensor Signal Inspection

NKS0006T

Symptom: Indication is malfunction of oil pressure gauge.

### 1. CHECK OIL PRESSURE SENSOR SIGNAL INPUT

1. Turn ignition switch ON.
2. Check voltage between triple meter harness connector M44 terminal 8 and ground.


**8 – Ground**

**When ignition switch is in ON position (Engine stopped.) : Approx. 1 V**

**Engine running [When the oil pressure is 80 psi (500 kpa)] : Approx. 3 V**

OK or NG

- OK >> Replace triple meter.
- NG >> GO TO 2.



SKIB1167E

# TRIPLE METERS


## 2. CHECK OIL PRESSURE SENSOR POWER SUPPLY

Check voltage between triple meter harness connector M44 terminal 9 and ground.

**9 – Ground : Approx. 5 V**

OK or NG

- OK >> GO TO 3.  
NG >> Replace triple meter.



## 3. CHECK OIL PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect triple meter and oil pressure switch connector.
3. Check continuity between triple meter harness connector M44 terminal 9 and oil pressure sensor harness connector F21 terminal 1.


**9 – 1 : Continuity should exist.**

4. Check continuity between triple meter harness connector M44 terminal 9 and ground.

**9 – Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 4.  
NG >> Repair harness or connector.



## 4. CHECK OIL PRESSURE SENSOR SIGNAL CIRCUIT

1. Check continuity between triple meter harness connector M44 terminal 8 and oil pressure sensor harness connector F21 terminal 2.


**8 – 2 : Continuity should exist.**

2. Check continuity between triple meter harness connector M44 terminal 8 and ground.

**8 – Ground :Continuity should not exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Repair harness or connector.




## 5. CHECK OIL PRESSURE SENSOR GROUND CIRCUIT

Check continuity between triple meter harness connector M44 terminal 7 and oil pressure sensor harness connector F21 terminal 3.

**7 – 3 : Continuity should exist.**

OK or NG

- OK >> Replace oil pressure sensor.  
NG >> Repair harness or connector.



# TRIPLE METERS

## Trip Computer Switch Inspection

NKS0006U

Symptom:

- Shift-up indicator setting indication is not displayed properly or shift-up indicator does not operate properly.
- Trip computer switch does not operate.

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Remove combination meter. Refer to [DI-26, "Removal and Installation for Combination Meter"](#) .
3. Remove rear finisher to combination meter. Refer to [DI-26, "Disassembly and Assembly for Combination Meter"](#) .
4. Check trip computer switch connector for looseness.

OK or NG

OK >> GO TO 2.

NG >> Repair trip computer switch connector.

### 2. CHECK CIRCUIT


1. Disconnect trip computer switch connector.
2. Check continuity between trip computer switch harness connector M208 terminals 3, 4 and 5.

Terminal		Condition	Continuity
3	5	Setting switch is pressed.	Yes
		Setting switch is released.	No
4		Mode switch is pressed.	Yes
		Mode switch is released.	No

OK or NG

OK >> Replace combination meter.


NG >> Replace trip computer switch.



## Removal and Installation of Triple Meters

NKS0006V

1. Remove cluster lid C. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Remove screws (2), and remove triple meters.



## INSTALLATION

Installation is the reverse order of removal.


# TRIPLE METERS

## Disassembly and Assembly for Triple Meters

NKS0006W

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

SEC.248



PKIA1763E

1. Screw
2. Front cover
3. Triple meter
4. Upper housing

### DISASSEMBLY

1. Remove screws (2), and remove front cover.
2. Disengage tabs (6) to separate upper housing.

### ASSEMBLY

Assembly is the reverse order of disassembly.


## UNIFIED METER AND A/C AMP

PFP:27760

### System Description DESCRIPTION

NKS0006X

- For the unified meter and A/C amp., the signal required for controlling the combination meter and triple meter are integrated in the A/C auto amp.
- Unified meter and A/C amp. corresponds a CONSULT-II function (self-diagnosis results, CAN diagnosis support monitor and data monitor).



### COMBINATION METER CONTROL FUNCTION

- Unified meter and A/C amp. receives necessary information for combination meter from each unit.
- Unified meter and A/C amp. converses with the combination meter transmits a signal through with communication line (TX, RX) between unified meter and A/C amp. and combination meter.

### Input/output signals between unified meter and A/C amp. and combination meter.

Unit	Input	Output
Unified meter and A/C amp.	<ul style="list-style-type: none"> <li>Seat belt buckle switch signal (Driver's side)</li> <li>Trip computer mode switch signal</li> <li>Trip computer setting switch signal</li> <li>Illumination control nighttime required signal</li> <li>Refuel status signal</li> <li>Vehicle speed signal</li> <li>Low-fuel warning lamp condition signal</li> <li>Self-diagnosis condition signal</li> <li>Odo/trip switch signal</li> <li>Delivery destination data signal</li> <li>Combination meter receive error signal</li> <li>Combination meter specifications signal</li> <li>Triple meter specifications signal</li> </ul>	<ul style="list-style-type: none"> <li>Engine speed signal</li> <li>Engine coolant temperature signal</li> <li>Fuel level sensor signal (resistance value)</li> <li>Malfunction indicator lamp signal</li> <li>ABS warning lamp signal</li> <li>Tire pressure warning lamp signal</li> <li>Brake warning lamp signal</li> <li>Oil pressure warning lamp signal</li> <li>Turn indicator signal</li> <li>High beam request signal</li> <li>VDC OFF indicator lamp signal</li> <li>TCS OFF indicator lamp signal</li> <li>SLIP indicator lamp signal</li> <li>CRUISE indicator lamp signal</li> <li>SET indicator lamp signal</li> <li>A/T CHECK indicator lamp signal</li> <li>A/T position indicator signal</li> <li>Manual mode indicator signal</li> <li>Manual mode gear position signal</li> <li>Shift-up indicator setting signal</li> <li>CAN communication condition signal of A/T</li> <li>Door switch signal</li> <li>Position lights request signal</li> <li>Buzzer output signal</li> </ul>

#### NOTE:

Combination meter performs fail-safe operation when unified meter and A/C amp. communication is malfunctioning. Refer to [DI-8](#). "FAIL-SAFE" .

# UNIFIED METER AND A/C AMP

## TRIPLE METER CONTROL FUNCTION

- Unified meter and A/C amp. receives necessary information for triple meter from each unit.
- Unified meter and A/C amp. calculates necessary information for trip computer.
- Unified meter and A/C amp. converses with the combination meter transmits a signal with through communication line (TX, RX) between unified meter and A/C amp. and triple meter.

### Input/output signals between unified meter and A/C amp. and triple meter

Unit	Input	Output
Unified meter and A/C amp.	<ul style="list-style-type: none"><li>● LCD indication condition signal</li><li>● Shift-up indicator setting signal</li><li>● Oil pressure warning lamp signal</li><li>● Triple meter receive error signal</li></ul>	<ul style="list-style-type: none"><li>● Ambient air temperature signal</li><li>● Ambient air temperature warning signal</li><li>● Trip distance signal</li><li>● Trip time signal</li><li>● Average vehicle speed signal</li><li>● Average fuel consumption signal</li><li>● Vehicle speed signal</li><li>● DTE (Distance to empty) signal</li><li>● DTE (Distance to empty) warning signal</li><li>● Tire pressure signal</li><li>● Tire pressure warning signal</li><li>● Trip computer mode switch signal</li><li>● Trip computer setting switch signal</li><li>● Self-diagnosis condition signal</li><li>● Odo/trip switch signal</li><li>● Triple meter specifications signal</li></ul>

#### NOTE:

Triple meter performs fail-safe operation when unified meter and A/C amp. communication is malfunctioning. Refer to [DI-31, "FAIL-SAFE"](#).

## A/C AUTO AMP. FUNCTION

Unified meter and A/C amp. controls each operation for A/C auto amp. Regarding A/C control, refer to [ATC-27, "AIR CONDITIONER CONTROL"](#) in ATC section.

## OTHER FUNCTIONS


### Signal Buffer Function

Unified meter and A/C amp. transmits each signal to other units with CAN communication.

## UNIFIED METER AND A/C AMP

## Schematic

NKS00070



\* : This relay is built into the IPDM E/R  
(Intelligent power distribution module engine room).

TKWT3992E



# UNIFIED METER AND A/C AMP

## CONSULT-II Function (METER A/C AMP)

NKS00071

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


System	Diagnosis mode	Description	Reference page
METER A/C AMP	SELF-DIAG RESULTS	Unified meter and A/C amp. check the conditions and displays memorized erro.	<a href="#">DI-50</a>
	DATA MONOTOR	Displays unified meter and A/C amp. input data in real time.	<a href="#">DI-51</a>
	CAN DIAG SUPPORT MNTR	The results of transmit/receive diagnosis of CAN communication can be read.	<a href="#">LAN-15</a>

## CONSULT-II BASIC OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With the ignition switch OFF, connect "CONSULT-II" and "CONSULT-II CONVERTER" to the data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "METER A/C AMP" on "SELECT SYSTEM" screen. If "METER A/C AMP" is not indicated, go to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# UNIFIED METER AND A/C AMP


4. Select "SELF-DIAG RESULTS", "CAN DIAG SUPPORT MNTR" or "DATA MONITOR" on "SELECT DIAG MODE" screen.



## SELF-DIAGNOSTIC RESULTS

### Operation Procedure

1. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
2. Self-diagnostic results are displayed.



### Display Item List

Display item [Code]	Malfunction is detected when...	Reference page
CAN COMM CIRC [U1000]	Malfunction is detected in CAN communication. <b>CAUTION:</b> Even when there is no malfunction on CAN communication system, malfunction may be misinterpreted when battery has low voltage (when maintaining 7 - 8 V for about 2 seconds) or 10A fuse [No. 19, located in the fuse block (J/B)] is disconnected.	<a href="#">DI-54</a>
T/METER COMM CIRC [B2201]	Malfunction is detected in communication of between triple meter and unified meter and A/C amp.	<a href="#">DI-54</a>
METER COMM CIRC [B2202]	Malfunction is detected in communication of between combination meter and unified meter and A/C amp.	<a href="#">DI-56</a>
VEHICLE SPEED CIRC [B2205]	When an erroneous signal is input. <b>CAUTION:</b> Even when there is no malfunction on speed signal system, malfunction may be misinterpreted when battery has low voltage (when maintaining 7 - 8 V for about 2 seconds).	<a href="#">DI-59</a>

### NOTE:

"TIME" means the following.

- 0: Means detected malfunction at present.
- 1-63: Means detected malfunction in past. (Displays number of ignition switch OFF → ON after detecting malfunction. "Self-diagnosis result" is erased when exceeding "63".)

# UNIFIED METER AND A/C AMP

## DATA MONITOR

### Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Touch either "MAIN SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

MAIN SIGNALS	Monitors main signals.
SELECTION FROM MENU	Selects and monitors individual signal.

3. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "MAIN SIGNALS" is selected, main items will be monitored.
4. Touch "START".
5. To record monitored item statue, touch "RECORD" while monitoring. To stop recording, touch "STOP".

Example)

DATA MONITOR	
MONITOR	
SPEED METER	0.0km/h
SPEED OUTPUT	0.0km/h
TACHO METER	0 rpm
W TEMP METER	26°C
FUEL METER	6 lit.
DISTANCE	0 km
FUEL W/L	ON
BUZZER	OFF
M RANGE SW	OFF
	Page Down
	STOP
MODE	BACK
LIGHT	COPY

SKIA4957E

### Display Item List

Monitor item [Unit]	MAIN SIGNALS	SELECTION FROM MENU	Contents
SPEED METER [km/h] or [mph]	X	X	This is the angle correction value after the speed signal from the VDC/TCS/ABS control unit [with VDC system] or ABS actuator and electric unit (control unit) [without VDC system] is converted into the vehicle speed.
SPEED OUTPUT [km/h] or [mph]	X	X	This is the angle correction value before the speed signal from the VDC/TCS/ABS control unit [with VDC system] or ABS actuator and electric unit (control unit) [without VDC system] is converted into the vehicle speed.
TACHO METER [rpm]	X	X	This is the converted value for the engine speed signal from the ECM.
W TEMP METER [°C] or [°F]	X	X	This is the converted value for the engine coolant temperature signal from the ECM.
FUEL METER [lit.]	X	X	This is the processed value for the signal (resistance value) from the fuel gauge.
DISTANCE [km] or [mile]	X	X	This is the calculated value for the speed signal from the VDC/TCS/ABS control unit [with VDC system] or ABS actuator and electric unit (control unit) [without VDC system] and the signal (resistance signal) from the fuel gauge.
FUEL W/L [ON/OFF]	X	X	Indicates [ON/OFF] condition of low-fuel warning lamp.
MIL [ON/OFF]		X	Indicates [ON/OFF] condition of malfunction indicator lamp.
AIR PRES W/L [ON/OFF]		X	Indicates [ON/OFF] condition of low tire pressure warning lamp.
SEAT BELT W/L [ON/OFF]		X	Indicates [ON/OFF] condition of seat belt warning lamp.
BUZZER [ON/OFF]	X	X	Indicates [ON/OFF] condition of buzzer.
DOOR W/L [ON/OFF]		X	Indicates [ON/OFF] condition of door warning lamp.
HI-BEAM IND [ON/OFF]		X	Indicates [ON/OFF] condition of high beam indicator.
TURN IND [ON/OFF]		X	Indicates [ON/OFF] condition of turn indicator.
OIL W/L [ON/OFF]		X	Indicates [ON/OFF] condition of oil pressure warning lamp.
VDC/TCS IND [ON/OFF]		X	Indicates [ON/OFF] condition of VDC/TCS OFF indicator lamp.

## UNIFIED METER AND A/C AMP

Monitor item [Unit]		MAIN SIGNALS	SELECTION FROM MENU	Contents
ABS W/L	[ON/OFF]		X	Indicates [ON/OFF] condition of ABS warning lamp.
SLIP IND	[ON/OFF]		X	Indicates [ON/OFF] condition of SLIP indicator lamp.
BRAKE W/L	[ON/OFF]		X	Indicates [ON/OFF] condition of brake warning lamp.*
M RANGE SW	[ON/OFF]	X	X	Indicates [ON/OFF] condition of manual mode range switch.
NM RANGE SW	[ON/OFF]	X	X	Indicates [ON/OFF] condition of except for manual mode range switch.
AT SFT UP SW	[ON/OFF]	X	X	Indicates [ON/OFF] condition of A/T shift up switch.
AT SFT DWN SW	[ON/OFF]	X	X	Indicates [ON/OFF] condition of A/T shift down switch.
AT P MODE SW	[ON/OFF]		X	Indicates [ON/OFF] condition of A/T power mode switch.
AT S MODE SW	[ON/OFF]		X	Indicates [ON/OFF] condition of A/T snow mode switch.
BRAKE SW	[ON/OFF]		X	Indicates [ON/OFF] condition of brake switch (stop lamp switch).
AT-M IND	[ON/OFF]	X	X	Indicates [ON/OFF] condition of A/T manual mode indicator.
AT-M GEAR	[5/4/3/2/1]	X	X	Indicates [5/4/3/2/1] condition of A/T manual mode gear position.
P RANGE IND	ON/OFF	X	X	Indicates [ON/OFF] condition of A/T shift P range indicator.
R RANGE IND	[ON/OFF]	X	X	Indicates [ON/OFF] condition of A/T shift R range indicator.
N RANGE IND	[ON/OFF]	X	X	Indicates [ON/OFF] condition of A/T shift N range indicator.
D RANGE IND	[ON/OFF]	X	X	Indicates [ON/OFF] condition of A/T shift D range indicator.
AT CHECK W/L	[ON/OFF]		X	Indicates [ON/OFF] condition of A/T CHECK warning lamp.
CRUISE IND	[ON/OFF]		X	Indicates [ON/OFF] condition of CRUISE indicator.
SET IND	[ON/OFF]		X	Indicates [ON/OFF] condition of SET indicator.

**NOTE:**

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

\*: Monitor keeps indicating "OFF" when brake warning lamp is on by the parking brake operation or low brake fluid level.

# UNIFIED METER AND A/C AMP

## Power Supply and Ground Circuit Inspection

NKS001M5

### 1. CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	19
Ignition switch ACC or ON	10,11
Ignition switch ON or START	12

OK or NG


OK >> GO TO 2.

NG >> Be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

### 2. CHECK POWER SUPPLY CIRCUIT

Check voltage between unified meter and A/C amp. harness connector terminals and ground.

Terminals		Ignition switch position		
(+) (–)		OFF	ACC	ON
Connector	Terminal			
M49	21	Battery voltage	Battery voltage	Battery voltage
M50	46	0 V	Battery voltage	Battery voltage
M49	22	0 V	0 V	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Check harness between unified meter and A/C amp. and fuse.

### 3. CHECK GROUND CIRCUIT


- Turn ignition switch OFF.
- Disconnect unified meter and A/C amp. connector.
- Check continuity between unified meter and A/C amp. harness connector and ground.

Connector	Terminal	Ground	Continuity
M49	29	Ground	Yes
	30		

OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.



# UNIFIED METER AND A/C AMP

## DTC [U1000] CAN Communication Circuit

NKS00072

Symptom: Display CAN COMM CIRC [U1000] at the result of self-diagnosis for unified meter and A/C amp.

### 1. CHECK CAN COMMUNICATION

1. Select "SELF-DIAG RESULTS" mode for "METER A/C AMP" with CONSULT-II.
2. Print out CONSULT-II screen.

>> Go to "LAN system". Refer to [LAN-3, "Precautions When Using CONSULT-II"](#).

## DTC [B2201] Triple Meter Communication Circuit

NKS00073

Symptom: Display T/METER COMM CIRC [B2201] at the result of self-diagnosis for unified meter and A/C amp.

### NOTE:

For the wiring diagram, refer to [DI-33, "Wiring Diagram — 3METER —"](#).

### 1. CHECK CONNECTOR

Check triple meter, unified meter and A/C amp. and terminals (triple meter side, unified meter and A/C amp. side, and harness side) for looseness or bent terminals.

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK METER/GAUGES VISUALLY

Does the pointer on the meter/gauges fluctuate at the engine start?

Is the fluctuation acceptable?

YES >> GO TO 3.

NO >> GO TO 6.

### 3. CHECK CONTINUITY COMMUNICATION CIRCUIT (TX: TRIPLE METER)

1. Turn ignition switch OFF.
2. Disconnect triple meter connector and unified meter and A/C amp. connector.
3. Check continuity between triple meter harness connector M44 terminal 4 and unified meter and A/C amp. harness connector M48 terminal 20.

**4 – 20 : Continuity should exist.**


4. Check continuity between triple meter harness connector M44 terminal 4 (P) and ground.

**4 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



# UNIFIED METER AND A/C AMP


## 4. CHECK VOLTAGE OF UNIFIED METER AND A/C AMP.

1. Connect unified meter and A/C amp. connector.
2. Turn ignition switch ON.
3. Check voltage between triple meter harness connector M44 terminal 4 and ground.

**4 – Ground : Approx. 5 V**

OK or NG



- OK >> GO TO 5.  
NG >> Replace unified meter and A/C amp.



## 5. CHECK VOLTAGE SIGNAL OF COMBINATION METER

1. Turn ignition switch OFF.
2. Connect triple meter connector.
3. Turn ignition switch ON.
4. Check voltage signal between triple meter harness connector M44 terminal 4 and ground.

**4 – Ground:**



OK or NG

- OK >> Replace unified meter and A/C amp.  
NG >> Replace triple meter.

## 6. CHECK CONTINUITY COMMUNICATION CIRCUIT (RX: TRIPLE METER)

1. Turn ignition switch OFF.
2. Disconnect triple meter connector and unified meter and A/C amp. connector.
3. Check continuity between triple meter harness connector M44 terminal 5 and unified meter and A/C amp. harness connector M48 terminal 10.


**5 – 10 : Continuity should exist.**

4. Check continuity between triple meter harness connector M44 terminal 5 and ground.

**5 – Ground : Continuity should not exist.**

OK or NG

- OK >> GO TO 7.  
NG >> Repair harness or connector.



# UNIFIED METER AND A/C AMP


## 7. CHECK VOLTAGE OF COMBINATION METER

1. Connect triple meter connector.
2. Turn ignition switch ON.
3. Check voltage between unified meter and A/C amp. harness connector M48 terminal 10 and ground.

**10 – Ground : Approx. 5 V**

OK or NG



- OK >> GO TO 8.  
NG >> Replace triple meter.



## 8. CHECK VOLTAGE SIGNAL OF UNIFIED METER AND A/C AMP.

1. Turn ignition switch OFF.
2. Connect triple meter connector and unified meter and A/C amp. connector.
3. Turn ignition switch ON.
4. Check voltage signal between triple meter harness connector M44 terminal 5 and ground.

**5 – Ground :**



OK or NG

- OK >> Replace triple meter.  
NG >> Replace unified meter and A/C amp.

## DTC [B2202] Meter Communication Circuit

NKS00074

Symptom: Display METER COMM CIRC [B2202] at the result of self-diagnosis for unified meter and A/C amp.

### NOTE:

For the wiring diagram, refer to [DI-12, "Wiring Diagram — METER —"](#).

## 1. CHECK CONNECTOR

Check combination meter, unified meter and A/C amp. and terminals (combination meter side, unified meter and A/C amp. side, and harness side) for looseness or bent terminals.

OK or NG

- OK >> GO TO 2.  
NG >> Repair terminal or connector.

## 2. CHECK METER/GAUGES VISUALLY

Does the pointer on the meter/gauges fluctuate at the engine start?

Is the fluctuation acceptable?

- YES >> GO TO 3.  
NO >> GO TO 6.



# UNIFIED METER AND A/C AMP

## 3. CHECK CONTINUITY COMMUNICATION CIRCUIT (TX: COMBINATION METER)

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector M19 terminal 21 and unified meter and A/C amp. harness connector M48 terminal 19.

**21 – 19 : Continuity should exist.**


4. Check continuity between combination meter harness connector M19 terminal 21 and ground.

**21 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



## 4. CHECK VOLTAGE OF UNIFIED METER AND A/C AMP.


1. Connect unified meter and A/C amp. connector.
2. Turn ignition switch ON.
3. Check voltage between combination meter harness connector M19 terminal 21 and ground.

**21 – Ground : Approx. 5 V**

OK or NG

OK >> GO TO 5.


NG >> Replace unified meter and A/C amp.



## 5. CHECK VOLTAGE SIGNAL OF COMBINATION METER

1. Turn ignition switch OFF.
2. Connect combination meter connector.
3. Turn ignition switch ON.
4. Check voltage signal between combination meter harness connector M19 terminal 21 and ground.


**21 – Ground:**



OK or NG

OK >> Replace unified meter and A/C amp.

NG >> Replace combination meter.



# UNIFIED METER AND A/C AMP

## 6. CHECK CONTINUITY COMMUNICATION CIRCUIT (RX: COMBINATION METER)

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector M19 terminal 22 and unified meter and A/C amp. harness connector M48 terminal 9.

**22 – 9 : Continuity should exist.**


4. Check continuity between combination meter harness connector M19 terminal 22 (L/OR) and ground.

**22 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 7.

NG >> Repair harness or connector.



## 7. CHECK VOLTAGE OF COMBINATION METER


1. Connect combination meter connector.
2. Turn ignition switch ON.
3. Check voltage between unified meter and A/C amp. harness connector M48 terminal 9 and ground.

**9 – Ground : Approx. 5 V**

OK or NG

OK >> GO TO 8.


NG >> Replace combination meter.



## 8. CHECK VOLTAGE SIGNAL OF UNIFIED METER AND A/C AMP.

1. Turn ignition switch OFF.
2. Connect unified meter and A/C amp. connector.
3. Turn ignition switch ON.
4. Check voltage signal between combination meter harness connector M19 terminal 22 and ground.


**22 – Ground:**



OK or NG

OK >> Replace combination meter.

NG >> Replace unified meter and A/C amp.



# UNIFIED METER AND A/C AMP

## DTC [B2205] Vehicle Speed Circuit

NKS00075

Symptom: Display VEHICLE SPEED CIRC [B2205] at the result of self-diagnosis for unified meter and A/C amp.

### 1. CHECK VDC/TCS/ABS CONTROL UNIT OR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform the following unit self-diagnosis.

- VDC/TCS/ABS control unit [with VDC]. Refer to [BRC-100, "CONSULT-II Functions \(VDC/TCS/ABS\)"](#).
- ABS actuator and electric unit (control unit) [without VDC]. Refer to [BRC-55, "CONSULT- II Functions \(TCS/ABS\)"](#) (with TCS) or [BRC-19, "CONSULT- II Functions \(ABS\)"](#) (without TCS).

#### Self-diagnostic results content

No malfunction detected>>Replace unified meter and A/C amp.


Malfunction detected>>Check applicable parts, and repair or replace corresponding parts.

## Removal and Installation of Unified Meter and A/C Amp.

NKS00076

### REMOVAL

1. Remove the console finisher (A/T) or console boot (M/T). Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove the fixing screws, then remove the unified meter and A/C amp.



### INSTALLATION

Installation is the reverse order of removal.

# WARNING LAMPS

---

## WARNING LAMPS

PFP:24814

### System Description

NKS00264

#### OIL PRESSURE WARNING LAMP


- Triple meter reads oil pressure signal from oil pressure sensor.
- Triple meter judges an oil pressure condition by oil pressure signal, and transmits oil pressure warning lamp signal to unified meter and A/C amp. with communication line.
- Unified meter and A/C amp. transmits oil pressure switch signal to combination meter with communication line.
- Combination meter turns oil pressure warning lamp according to oil pressure switch signal.

# WARNING LAMPS

## Schematic

NKS00077

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M



**NOTE:**  
For the further details, refer to descriptions on each system.




TKWT2306E

# WARNING LAMPS

## Wiring Diagram — WARN —

NKS00078

DI-WARN-01





REFER TO THE FOLLOWING.

M4 - FUSE BLOCK-JUNCTION BOX (J/B)

TKWT0485E

# WARNING LAMPS








★: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(F101) -ELECTRICAL UNITS

TKWM1319E





REFER TO THE FOLLOWING.  
 (F102), (B1) -SUPER MULTIPLE  
 JUNCTION (SMJ)



# WARNING LAMPS

DI-WARN-04




REFER TO THE FOLLOWING.  
 (E108), (F102), (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)



TKWT3994E

## WARNING LAMPS

DI-WARN-05

 : DATA LINE

 : COUPE MODELS



REFER TO THE FOLLOWING.

**(B1) -SUPER MULTIPLE JUNCTION (SMJ)**

(M90), (B83) -ELECTRICAL  
UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

A

B



E

F

G

H

1

J







DI

L

M

# WARNING LAMPS

DI-WARN-07



REFER TO THE FOLLOWING.  
 (E108) -SUPER MULTIPLE JUNCTION (SMJ)

TKWT3997E

# WARNING LAMPS

DI-WARN-08


— : DATA LINE

WV : WITH VDC SYSTEM

OV : WITHOUT VDC SYSTEM

TS : WITH TCS WITHOUT VDC SYSTEM

VT : WITH VDC SYSTEM OR TCS



REFER TO THE FOLLOWING.

E108 -SUPER MULTIPLE JUNCTION (SMJ)

E51, E118 -ELECTRICAL UNITS

TKWT1635E

# WARNING LAMPS

## CONSULT-II Function (METER A/C AMP)

NKS00079

Refer to [DI-49, "CONSULT-II Function \(METER A/C AMP\)"](#) in "UNIFIED METER AND A/C AMP".

### Oil Pressure Warning Lamp Stays Off (Ignition Switch ON) or Stays On (Oil Pressure Is Normal)

NKS0007A

#### NOTE:

For oil pressure inspection, refer to [LU-8, "OIL PRESSURE CHECK"](#) .

#### 1. CHECK OIL PRESSURE GAUGE

Start the engine.

Does oil pressure gauge operate?

YES >> GO TO 2.

NO >> Check oil pressure sensor signal.

#### 2. CHECK COMMUNICATION LINE

Perform self-diagnosis of unified meter and A/C amp. Refer to [DI-49, "CONSULT-II Function \(METER A/C AMP\)"](#) .

Self-diagnostic results

No malfunction detected>>GO TO 3.

Malfunction detected>>Check applicable parts, and repair or replace corresponding parts.

#### 3. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select "METER A/C AMP" on CONSULT-II. Operate ignition switch with "OIL W/L" of "DATA MONITOR" and check operation status.

**"OIL W/L"**

**When ignition switch is in ON : ON**  
**position (Engine stopped.)**

**When engine running : OFF**

OK or NG

OK >> Replace combination meter.

NG >> Replace triple meter.

DATA MONITOR	
MONITOR	
OIL W/L	ON

PKIA2064E

## A/T INDICATOR

PFP:24814

### System Description

NKS00265


A/T position is displayed in the A/T indicator in the combination meter.

#### MANUAL MODE

- Unified meter and A/C amp. reads manual mode signal and shift-up/down signal from A/T device, and transmits the signals to TCM with CAN communication.
- TCM processes manual mode signal and shift-up/down signal, and transmits manual mode indicator signal and A/T position indicator signal to unified meter and A/C amp. with CAN communication.
- Unified meter and A/C amp. transmits manual mode indicator signal and A/T position indicator signal to combination meter with the communication line.
- Combination meter displays A/T gear position and manual mode indicator according to A/T position indicator signal and manual mode indication signal.

#### NOT MANUAL MODE

- Unified meter and A/C amp. reads not manual mode signal from A/T device, and transmits the signals to TCM with CAN communication.
- TCM transmits A/T position indicator signal to unified meter and A/C amp. with CAN communication.
- Unified meter and A/C amp. transmits A/T position indicator signal to combination meter with the communication line.
- Combination meter displays A/T shift position according to A/T position indicator signal.







# A/T INDICATOR

## Wiring Diagram — AT/IND —

NKS0007B

DI-AT/IND-01

■ : DATA LINE



★: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)


(M4) -FUSE BLOCK-JUNCTION BOX (J/B)

TKWT3998E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

 : DATA LINE



# A/T INDICATOR

## CONSULT-II Function (METER A/C AMP)

NKS0007C

Refer to [DI-49, "CONSULT-II Function \(METER A/C AMP\)"](#) in "UNIFIED METER AND A/C AMP".

### A/T Indicator Is Malfunction

NKS0007D


#### 1. CHECK A/T INDICATOR SEGMENTS

Perform self-diagnosis mode of combination meter. Refer to [DI-16, "OPERATION PROCEDURE"](#).

Are all segments displayed?

YES >> GO TO 2.

NO >> Replace combination meter.



PKIA1856E

#### 2. CHECK UNIFIED METER AND A/C AMP. (CONSULT-II)

Perform self-diagnosis of unified meter and A/C amp. Refer to [DI-49, "CONSULT-II Function \(METER A/C AMP\)"](#).

Self-diagnostic results

No malfunction detected>>GO TO 3.

Malfunction detected>> Check applicable parts, and repair or replace corresponding parts.

#### 3. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Use "DATA MONITOR" of "METER A/C AMP" on CONSULT-II. Confirm each indication on the monitor when shifting the selector lever.

CONSULT-II display	Selector lever position	Status
AT-M IND	Manual mode range	ON
	Except for manual mode range	OFF
AT-M GEAR	Manual mode range (shift up or down)	5-1
	Except for manual mode range	1
P RANGE IND	P range	ON
	Except for P range	OFF
R RANGE IND	R range	ON
	Except for R range	OFF
N RANGE IND	N range position	ON
	Except for N range	OFF
D RANGE IND	D range position	ON
	Except for D range	OFF

DATA MONITOR	
MONITOR	
AT-M IND	OFF
AT-M GEAR	1
P RANGE IND	ON
R RANGE IND	OFF
N RANGE IND	OFF
D RANGE IND	OFF

SKIA6259E

OK or NG

OK >> Replace combination meter.

NG >> GO TO 4.

#### 4. CHECK TCM (CONSULT-II)

Perform TCM self-diagnosis. Refer to [AT-89, "CONSULT-II Function \(A/T\)"](#).

Self-diagnostic results

No malfunction detected>>Replace unified meter and A/C amp.

Malfunction detected>>Check applicable parts, and repair or replace corresponding parts.

## WARNING CHIME

PFP:24814

### System Description


NKS00266

- The buzzer for warning chime system is installed in the combination meter.
- The buzzer sounds when the combination meter receives buzzer output signal from each unit through unified meter and A/C amp.

### IGNITION KEY WARNING CHIME

With the key inserted into the key switch, and the ignition switch in OFF or ACC position, when driver's door is open, the ignition key warning chime sounds.


- BCM detects key inserted into the key switch, ignition switch in OFF or ACC position, and driver side door switch ON. And then, BCM transmits buzzer output signal (ignition key warning chime) to unified meter and A/C amp. with CAN communication.
- Unified meter and A/C amp. transmits buzzer output signal (ignition key warning chime) to combination meter with communication line.
- When combination meter receives buzzer output signal (ignition key warning chime), it sounds the buzzer.



### LIGHT WARNING CHIME

With ignition switch in OFF or ACC position, drivers door open, and lighting switch in 1ST or 2ND position, the light warning chime will sounds.

- BCM detects ignition switch in OFF or ACC position, driver side door switch ON, and lighting switch in 1ST or 2ND position. And then, BCM transmits buzzer output signal (light warning chime) to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits buzzer output signal (light warning chime) to combination meter with communication line.
- When combination meter receives buzzer output signal (light warning chime), it sounds the buzzer.



#### NOTE:


For further details of combination switch, refer to [LT-97. "Combination Switch Reading Function"](#).

# WARNING CHIME

## SEAT BELT WARNING CHIME


With ignition switch turned ON and driver seat belt unfastened, seat belt warning chime sounds for approximately 6 seconds.

- Combination meter reads a ON/OFF signal from seat belt buckle switch, and transmits seat belt buckle switch signal to unified meter and A/C amp. with communication line.
- BCM receives seat belt buckle switch signal from unified meter and A/C amp. with CAN communication line.
- BCM detects ignition switch turned ON and seat belt buckle switch (driver side) ON. And then, BCM transmits buzzer output signal (seat belt warning chime) to unified meter and A/C amp. with CAN communication.
- Unified meter and A/C amp. transmits buzzer output signal (seat belt warning chime) to combination meter with communication line.
- When combination meter receives buzzer output signal (seat belt warning chime), it sounds the buzzer.



## Component Parts and Harness Connector Location


NKS0007F



## WARNING CHIME

## Schematic

NKS00071



TKWT2310E



M

# WARNING CHIME

## Wiring Diagram — CHIME —

NKS0007J

### DI-CHIME-01



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)



(M4), (M5) -FUSE BLOCK-JUNCTION BOX (J/B)

(M90), (M91), (B83) -ELECTRICAL UNITS


TKWT3999E

WARNING CHIME


DI-CHIME-02




(M8)  
W



(M48)  
GY



(M49)  
GY







(M78)  
W

REFER TO THE FOLLOWING.  
(M4) -FUSE BLOCK-JUNCTION BOX (J/B)  
(M90, M91) -ELECTRICAL UNITS

# WARNING CHIME

## DI-CHIME-03



REFER TO THE FOLLOWING.

- (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M4) -FUSE BLOCK-JUNCTION BOX (J/B)





TKWT4000E



# WARNING CHIME


## Terminals and Reference Value for BCM

NKS0007K


Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Igni- tion switch	Operation or condition	
2	GY	Combination switch input 5	ON	OFF	0 V
				Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 1ST</li> <li>● Lighting switch HIGH beam (Operates only HIGH beam switch)</li> <li>● Turn signal switch to right</li> </ul>	 <p>1.0 V</p>
				Lighting switch 2ND	 <p>2.0 V</p>
3	L/W	Combination switch input 4	ON	OFF	0 V
				Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> <li>● Turn signal switch to left</li> </ul>	 <p>1.0 V</p>
4	PU/W	Combination switch input 3	ON	OFF	0 V
				Any of the conditions below <ul style="list-style-type: none"> <li>● Front wiper switch MIST</li> <li>● Front wiper switch INT</li> <li>● Front wiper switch LO</li> </ul>	 <p>1.0 V</p>

# WARNING CHIME


Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
5	Y/R	Combination switch input 2	ON	Lighting, turn, wiper switch	OFF (Wiper intermittent dial position 4)
				Lighting, turn, wiper switch	Any of the conditions below <ul style="list-style-type: none"> <li>● Front washer switch</li> <li>● Rear washer switch</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 5</li> <li>● Wiper intermittent dial position 6</li> </ul>
				Lighting, turn, wiper switch	Rear wiper switch ON (Wiper intermittent dial position 4)
6	Y/G	Combination switch input 1	ON	Lighting, turn, wiper switch	OFF (Wiper intermittent dial position 4)
				Lighting, turn, wiper switch	Any of the conditions below <ul style="list-style-type: none"> <li>● Front wiper switch HI</li> <li>● Rear wiper switch INT</li> <li>● Wiper intermittent dial position 3</li> </ul>
				Lighting, turn, wiper switch	Any of the conditions below <ul style="list-style-type: none"> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 2</li> </ul>
				Lighting, turn, wiper switch	Any of the conditions below <ul style="list-style-type: none"> <li>● Wiper intermittent dial position 6</li> <li>● Wiper intermittent dial position 7</li> </ul>




1.0 V




0.8 v



1.0 V







1.7 V









0.8 V

# WARNING CHIME

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
18	B	Remote key-less entry receiver (Ground)	—	—	Refer to <a href="#">WT-20. "Control Unit Input/Output Signal Standard"</a> .
19	Y	Remote key-less entry receiver (Power supply)			
20	L	Remote key-less entry receiver (Signal)			
32	G/B	Combination switch output 5	ON	Lighting, turn, wiper switch	 <p>7.2 V</p>
				Any of the conditions below	 <p>1.0 V</p>
33	G	Combination switch output 4	ON	Lighting, turn, wiper switch	 <p>7.2 V</p>
				Any of the conditions below	 <p>1.2 V</p>

# WARNING CHIME



Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
34	W/L	Combination switch output 3	ON	Lighting, turn, wiper switch	 <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
				Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch HI beam (Operates only HI beam switch)</li> <li>● Rear washer switch</li> <li>● Wiper intermittent dial position 1</li> <li>● Wiper intermittent dial position 2</li> <li>● Wiper intermittent dial position 3</li> </ul>	 <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
35	W/G	Combination switch output 2	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	 <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
				Any of the conditions below <ul style="list-style-type: none"> <li>● Lighting switch 2ND</li> <li>● Lighting switch PASSING (Operates only PASSING switch)</li> <li>● Front wiper switch INT</li> <li>● Front wiper switch HI</li> </ul>	 <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
36	W/R	Combination switch output 1	ON	Lighting, turn, wiper switch (Wiper intermittent dial position 4)	 <p style="text-align: right;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
				Any of the conditions below <ul style="list-style-type: none"> <li>● Turn signal switch to right</li> <li>● Turn signal switch to left</li> <li>● Front wiper switch MIST</li> <li>● Front wiper switch LO</li> <li>● Front washer switch</li> </ul>	 <p style="text-align: right;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>

# WARNING CHIME

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
37	B/R	Key switch signal	OFF	Key is removed.	0 V
				Key is inserted.	12 V
38	W/L	Ignition power supply	ON	—	Battery voltage
39	L	CAN-H	—	—	—
40	P	CAN-L	—	—	—
42	GY	Battery power supply (FUSE)	OFF	—	Battery voltage
52	B	Ground	ON	—	0 V
55	R	Battery power supply (F/L)	OFF	—	Battery voltage
62	L	Driver side door switch signal	OFF	Door switch is released. (Door switch ON)	0 V
				Door switch is pressed. (Door switch OFF)	5 V

## Terminals and Reference Value for Unified Meter and A/C Amp.

NKS0007L



Terminal No.	Wire color	Item	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
1	L	CAN-H	OFF	—	—
9	L/OR	TX communication line (To combination meter)	ON	—	 SKIA3362E
11	P	CAN-L	OFF	—	—
19	R/G	RX communication line (From combination meter)	ON	—	 SKIA3361E
21	R/W	Battery power supply	OFF	—	Battery voltage
22	Y/G	Ignition power supply	ON	—	Battery voltage
29	B	Ground (POWER)	ON	—	0 V
30	B	Ground	ON	—	0 V

## Terminals and Reference Value for Combination Meter

NKS0007M

Terminal No.	Wire color	Item	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
1	BR/Y	Seat belt buckle switch (Driver side)	ON	Seat belt is unfastened.	0 V
				Seat belt is fastened.	5 V

# WARNING CHIME

Terminal No.	Wire color	Item	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
10	B	Ground	ON	—	0 V
11					
12					
21	R/G	TX communication line (To unified meter and A/C amp.)	ON	—	 <small>SKIA3361E</small>
22	L/OR	RX communication line (From unified meter and A/C amp.)	ON	—	 <small>SKIA3362E</small>
23	G/Y	Ignition power supply	ON	—	Battery voltage
24	R/W	Battery power supply	OFF	—	Battery voltage

## WARNING CHIME

### CONSULT-II Function (METER A/C AMP)

NKS00070

Refer to [DI-49, "CONSULT-II Function \(METER A/C AMP\)"](#) in "UNIFIED METER AND A/C AMP".

### CONSULT-II Function (BCM)

NKS0007P

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

#### DIAGNOSTIC ITEMS DESCRIPTION


System	Test item	Diagnosis mode	Description	Reference page
BCM	BCM	SELF-DIAG RESULT	BCM performs self-diagnosis of CAN communication.	<a href="#">DI-89</a>
	BUZZER	DATA MONITOR	The input data to the BCM control unit is displayed in real time.	<a href="#">DI-88</a>
		ACTIVE TEST	Operation of electrical loads can be checked by sending driving signal to them.	<a href="#">DI-88</a>

#### CONSULT-II BASIC OPERATION PROCEDURE


##### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With the ignition switch OFF, connect "CONSULT-II" and CONSULT-II CONVERTER" to the data link connector, and turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, go to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



## WARNING CHIME

4. Touch "BUZZER" or "BCM".
5. Select "DATA MONITOR", "ACTIVE TEST" or "SELF-DIAG RESULTS".



### DATA MONITOR

#### Operation Procedure

1. Touch "BUZZER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch "ALL SIGNALS" or "SELECTION FROM MENU" on "DATA MONITOR" screen.

ALL SIGNALS	Monitors all items.
SELECTION FROM MENU	Selects and monitors items.

4. If "SELECTION FROM MENU" is selected, touch the desired monitor item. If "ALL SIGNALS" is selected, all items required to control are monitored.
5. Touch "START".
6. During monitoring, touching "RECORD" can start recording the monitored item status.

#### Display Item List

Monitor item [Unit]	ALL SIGNALS	SELECTION FROM MENU	Contents
IGN ON SW [ON/OFF]	X	X	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW [ON/OFF]	X	X	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR [ON/OFF]	X	X	Indicates [ON/OFF] condition of driver side door switch.
LIGHT SW 1ST [ON/OFF]	X	X	Indicates [ON/OFF] condition of lighting switch.
BUCKLE SW [ON/OFF]	X	X	Indicates [ON/OFF] condition of seat belt switch.

### ACTIVE TEST

#### Operation Procedure

1. Touch "BUZZER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch the item to be tested, and check the operation.
4. During the operation check, touching "OFF" deactivates the operation.

#### Display Item List

Test item	Malfunction is detected when...
LIGHT WARN ALM	This test is able to check light warning chime operation.
IGN KEY WARN ALM	This test is able to check ignition key warning chime operation.
SEAT BELT WARN ALM	This test is able to check seat belt warning chime operation.



# WARNING CHIME

## SELF-DIAGNOSTIC RESULTS

### Operation Procedure

1. Touch "BCM" on "SELECT TEST ITEM" screen.
2. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
3. Self-diagnostic results are displayed.

### Display Item List

Display item [Code]	Malfunction is detected when...
CAN communication [U1000]	Malfunction is detected in CAN communication.

#### NOTE:

If "CAN communication [U1000]" is indicated, after printing the monitor item, go to "CAN system". Refer to [LAN-3, "Precautions When Using CONSULT-II"](#) .

## Trouble Diagnosis

NKS00267

### HOW TO PERFORM TROUBLE DIAGNOSIS

1. Confirm the symptom and customer complaint.
2. Understand the outline of system. Refer to [DI-75, "System Description"](#) .
3. Perform the preliminary inspection. Refer to [DI-89, "PRELIMINARY INSPECTION"](#) .
4. Referring to trouble diagnosis chart, make sure the cause of the malfunction and repair or replace applicable parts. Refer to [DI-90, "Symptom Chart"](#) .
5. Does warning chime system operate normally? If yes, GO TO 6. If no, GO TO 4.
6. INSPECTION END

### PRELIMINARY INSPECTION

#### 1. CHECK BCM (CONSULT-II)

Perform self-diagnosis of BCM. Refer to [BCS-15, "CONSULT-II Function \(BCM\)"](#) .

##### Self-diagnostic results

No malfunction detected>> GO TO 2.

Malfunction detected>> Check applicable parts, and repair or replace corresponding parts.

#### 2. CHECK UNIFIED METER AND A/C AMP. (CONSULT-II)

Perform self-diagnosis of unified meter and A/C amp. Refer to [DI-49, "CONSULT-II Function \(METER A/C AMP\)"](#) .

##### Self-diagnostic results

No malfunction detected>> INSPECTION END

Malfunction detected>> Check applicable parts, and repair or replace corresponding parts.

# WARNING CHIME

## Symptom Chart

NKS00268

Symptom	Diagnoses/Service procedure
All warning chimes do not activate.	Perform the following inspections. 1. <a href="#">DI-90, "Power Supply and Ground Circuit Inspection"</a> . 2. <a href="#">DI-91, "Meter Buzzer Circuit Inspection"</a> . Replace BCM, found normal function in the above inspections.
Ignition key warning chime does not activate.	Perform the following inspections. 1. <a href="#">DI-93, "Key Switch Signal Inspection"</a> . 2. <a href="#">DI-92, "Driver Side Door Switch Signal Inspection"</a> . Replace BCM, found normal function in the above inspection.
Light warning chime does not activate.	Perform the following inspections. 1. <a href="#">DI-94, "Lighting Switch Signal Inspection"</a> . 2. <a href="#">DI-92, "Driver Side Door Switch Signal Inspection"</a> . Replace BCM, found normal function in the above inspection.
Seat belt warning chime does not activate.	Perform <a href="#">DI-95, "Seat Belt Buckle Switch (Driver Side) Signal Inspection"</a> . Replace BCM, found normal function in the above inspection.

## Power Supply and Ground Circuit Inspection

NKS00269

### 1. CHECK FUSE AND FUSIBLE LINK

Check for blown BCM fuse and fusible link.

Unit	Power source	Fuse and fusible link No.
BCM	Battery	F
		18
	Ignition switch ON or START	1

OK or NG

OK >> GO TO 2.

NG >> Be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

### 2. CHECK POWER SUPPLY CIRCUIT


Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position	
(+) (Wire color)		OFF	ON
Connector	Terminal		
M91	42	Battery voltage	Battery voltage
	55		
M90	38	0 V	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Repair harness between BCM and fuse.



# WARNING CHIME


## 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector M91 terminal 52 and ground.

**52 – Ground : Continuity should exist.**

OK or NG

- OK >> INSPECTION END  
NG >> Repair harness or connector.



NKS0026F


## Meter Buzzer Circuit Inspection

### 1. CHECK OPERATION OF METER BUZZER

1. Select "BUZZER" of "BCM" on CONSULT-II.
2. Perform "LIGHT WARN ALM", "IGN KEY WARN ALM" or "SEAT BELT WARN ALM" of "ACTIVE TEST".

Does meter buzzer beep?

- YES >> GO TO 3.  
NO >> GO TO 2.



### 2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Select "METER A/C AMP" on CONSULT-II.
2. With "DATA MONITOR", confirm "BUZZER" under the condition of buzzer input. (Seat belt warning chime, turn signal lamp operate, etc.)


**"BUZZER"**

**Under the condition of buzzer input : ON**

**Except above : OFF**

OK or NG

- OK >> Replace combination meter.  
NG >> Replace BCM. Refer to [BCS-18, "Removal and Installation of BCM"](#).



### 3. CHECK BATTERY POWER SUPPLY OF COMBINATION METER

Check battery power supply of combination meter. Refer to [DI-18, "Power Supply and Ground Circuit Inspection"](#) in combination meter.

OK or NG

- OK >> GO TO 4.  
NG >> Repair battery power supply circuit of combination meter.

## WARNING CHIME

### 4. CHECK BATTERY POWER SUPPLY OF UNIFIED METER AND A/C AMP.

Check battery power supply of unified meter and A/C amp. Refer to [DI-53, "Power Supply and Ground Circuit Inspection"](#) in unified meter and A/C amp.

OK or NG

- OK >> Replace BCM. Refer to [BCS-18, "Removal and Installation of BCM"](#) .  
NG >> Repair battery power supply circuit of unified meter and A/C amp.

### Driver Side Door Switch Signal Inspection

NKS0026A

#### 1. CHECK BCM INPUT SIGNAL


 With CONSULT-II

1. Select "BCM".
2. With "DATA MONITOR" of "BUZZER", confirm "DOOR SW-DR" when the driver side door is operated.

**"DOOR SW-DR"**

**When driver side door is opened : ON**

**When driver side door is closed : OFF**




 Without CONSULT-II

Check voltage between BCM harness connector B83 terminal 62 and ground.

**62 – Ground**

**When driver side door is opened : Approx. 0 V**

**When driver side door is closed : Approx. 5 V**



OK or NG

- OK >> INSPECTION END  
NG >> GO TO 2.


#### 2. CHECK DRIVER SIDE DOOR SWITCH CIRCUIT

1. Disconnect BCM connector and driver side door switch connector.
2. Check continuity between BCM harness connector B83 terminal 62 and driver side door switch harness connector B17 terminal 1.

**62 – 1 : Continuity should exist.**

3. Check continuity between BCM harness connector B4 terminal 62 (W) and ground.

**62 – Ground : Continuity should not exist.**



OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.

#### 3. CHECK DRIVER SIDE DOOR SWITCH

Check driver side door switch. Refer to [DI-96, "DRIVER SIDE DOOR SWITCH"](#) .

OK or NG

- OK >> Replace BCM. Refer to [BCS-18, "Removal and Installation of BCM"](#) .  
NG >> Replace driver side door switch.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

NKS0026B

## DI

L

M



## WARNING CHIME

### 4. CHECK KEY SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M90 terminal 37 and key switch harness connector M25 terminal 1.

**37 – 1 : Continuity should exist.**


3. Check continuity between BCM harness connector M90 terminal 37 and ground.

**37 – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.



### 5. CHECK KEY SWITCH POWER SUPPLY CIRCUIT


Check voltage between key switch harness connector M25 terminal 2 and ground.

**2 – Ground : Battery voltage**

OK or NG

OK >> Replace BCM. Refer to [BCS-18, "Removal and Installation of BCM"](#).

NG >> Check continuity between key switch and fuse.



## Lighting Switch Signal Inspection

### 1. CHECK BCM INPUT SIGNAL

1. Select "BCM" on CONSULT-II.
2. With "DATA MONITOR" of "BUZZER", confirm "LIGHT SW 1ST" when the lighting switch is operated.

**"LIGHT SW 1ST"**


**Lighting switch (1st position) : ON**

**Lighting switch (OFF) : OFF**

OK or NG

OK >> INSPECTION END

NG >> Check lighting switch. Refer to [LT-103, "Combination Switch Inspection"](#).



# WARNING CHIME

## Seat Belt Buckle Switch (Driver Side) Signal Inspection

NKS0026D

### 1. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) SIGNAL INPUT (BCM)

1. Select "BCM" on CONSULT-II.
2. With "DATA MONITOR" of "BUZZER", confirm "BUCKLE SW" when the seat belt buckle switch (driver side) is operated.

#### "BUCKLE SW"


When seat belt is fastened : OFF

When seat belt is unfastened : ON

OK or NG

OK >> INSPECTION END

NG >> GO TO 2.



### 2. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) SIGNAL INPUT (COMBINATION METER)

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector M19 terminal 1 and ground.

#### 1 – Ground


When seat belt is fastened : Approx. 12 V

When seat belt is unfastened : Approx. 0 V

OK or NG

OK >> Replace combination meter.

NG >> GO TO 3.



### 3. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and seat belt buckle switch (driver side) connector.
3. Check continuity between combination meter harness connector M19 terminal 1 and seat belt buckle switch (driver side) harness connector B8 terminal 1.

1 – 1 : Continuity should exist.


4. Check continuity between combination meter harness connector M19 terminal 1 and ground.

1 – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



### 4. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check seat belt buckle switch (driver side). Refer to [DI-96. "SEAT BELT BUCKLE SWITCH \(DRIVER SIDE\)"](#).

OK or NG

OK >> Check seat belt buckle switch (driver side) ground circuit.

NG >> Replace seat belt buckle switch (driver side).

# WARNING CHIME

## Component Inspection DRIVER SIDE DOOR SWITCH


NKS0026E

Check continuity between terminal 1 and door switch case ground.

### 1 – Door switch case ground

When driver side door switch is released : Continuity should exist.

When driver side door switch is pressed : Continuity should not exist.




## SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check continuity between terminals 1 and 2.

### 1 – 2

When seat belt (driver side) is fastened : Continuity should not exist.

When seat belt (driver side) is unfastened : Continuity should exist.




## KEY SWITCH

Check continuity between key switch terminals 1 and 2.

### 1 – 2

When key is inserted to ignition key cylinder : Continuity should exist.

When key is removed from ignition key cylinder : Continuity should not exist.





CAN COMMUNICATION

PFP:23710

System Description

NKS001M6

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

NKS001M7

Refer to [LAN-24, "CAN Communication Unit"](#) in "LAN SYSTEM".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
DI  
L  
M

# CAN COMMUNICATION

---