

CLUTCH


SECTION **CL**

CONTENTS

PRECAUTIONS AND PREPARATION	CL- 2
CLUTCH SYSTEM	CL- 4
INSPECTION AND ADJUSTMENT	CL- 5
HYDRAULIC CLUTCH CONTROL	CL- 6
CLUTCH RELEASE MECHANISM	CL- 8
CLUTCH DISC AND CLUTCH COVER	CL-10
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	CL-12

CL

PRECAUTIONS AND PREPARATION



Precautions

- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use Tool.
- Use new brake fluid to clean or wash all parts of master cylinder, operating cylinder and clutch damper.
- Never use mineral oils such as gasoline or kerosene. It will ruin the rubber parts of the hydraulic system.





WARNING:

After cleaning the clutch disc, wipe it with a dust collector. Do not use compressed air.

Preparation

SPECIAL SERVICE TOOLS



*: Special tool or commercial equivalent

Tool number Tool name	Description
ST20050010 Base plate	 Inspecting diaphragm spring of clutch cover
ST20050100 Distance piece	 Inspecting diaphragm spring of clutch cover
GG94310000* Flare nut torque wrench	 Removing and installing each clutch piping
ST20600000* Clutch aligning bar	 Installing clutch cover and clutch disc
ST20050240* Diaphragm spring adjusting wrench	 Adjusting unevenness of diaphragm spring of clutch cover


PRECAUTIONS AND PREPARATION

Preparation (Cont'd)

COMMERCIAL SERVICE TOOLS

Tool name	Description
Bearing puller	 Removing release bearing
Bearing drift	 Installing release bearing a: 50 mm (1.97 in) dia.


CLUTCH SYSTEM



CL-4

[Symbol] : N.m (kg-m, ft-lb)
 [Symbol] : Apply lithium-based grease including molybdenum disulphide.

SCL356



Adjusting Clutch Pedal

1. Adjust pedal height with pedal stopper.

Pedal height "H":

L.H. 186 - 196 mm (7.32 - 7.72 in)

R.H. 182 - 192 mm (7.17 - 7.56 in)



2. Adjust pedal free play with master cylinder push rod. Then tighten lock nut.

Pedal free play "A":

1.0 - 3.0 mm (0.039 - 0.118 in)

Pedal free play means the following total measured at position of pedal pad:

- Play due to clevis pin and clevis pin hole in clutch pedal.
- Play due to piston and push rod.



Bleeding Procedure

Bleed air according to the following procedure.

Clutch connector → Clutch operating cylinder

- Carefully monitor fluid level at master cylinder during bleeding operation.
1. Top up reservoir with recommended brake fluid.
 2. Connect a transparent vinyl tube to air bleeder valve.
 3. Fully depress clutch pedal several times.
 4. With clutch pedal depressed, open bleeder valve to release air.
 5. Close bleeder valve.
 6. Repeat steps 3 through 5 above until brake fluid flows from air bleeder valve without air bubbles.


HYDRAULIC CLUTCH CONTROL

Clutch Master Cylinder (Cont'd)

INSPECTION

- Check cylinder and piston rubbing surface for uneven wear, rust or damage. Replace if necessary.
- Check piston with piston cup for wear or damage. Replace if necessary.
- Check return spring for wear or damage. Replace if necessary.
- Check reservoir for deformation or damage. Replace if necessary.
- Check dust cover for cracks, deformation or damage. Replace if necessary.

Operating Cylinder




SCL356

INSPECTION


- Check rubbing surface of cylinder for wear, rust or damage. Replace if necessary.
- Check piston with piston cup for wear or damage. Replace if necessary.
- Check piston spring for wear or damage. Replace if necessary.
- Check dust cover for cracks, deformation or damage. Replace if necessary.

Clutch Master Cylinder



DISASSEMBLY AND ASSEMBLY


- Push piston into cylinder body with screwdriver when removing and installing valve stopper.



CLUTCH RELEASE MECHANISM

INSPECTION

- Check release bearing to see that it rolls freely and is free from noise, cracks, pitting or wear. Replace if necessary.
- Check release sleeve and withdrawal lever rubbing surface for wear, rust or damage. Replace if necessary.




LUBRICATION

- Apply recommended grease to contact surface and rubbing surface.


Too much lubricant might damage clutch disc facing.

CLUTCH RELEASE MECHANISM




REMOVAL AND INSTALLATION


- Install retainer spring and holder spring.



- Remove release bearing.



- Install release bearing with suitable drift.



CLUTCH DISC AND CLUTCH COVER

Clutch Cover and Flywheel



INSPECTION AND ADJUSTMENT

- Set Tool and check height and unevenness of diaphragm spring.

Diaphragm spring height "A":

33.0 - 35.0 mm (1.299 - 1.378 in)

- Check thrust rings for wear or damage by shaking cover assembly and listening for chattering noise, or lightly hammering on rivets for a slightly cracked noise. Replace clutch cover assembly if necessary.
- Check pressure plate and clutch disc contact surface for slight burns or discoloration. Repair pressure plate with emery paper.
- Check pressure plate and clutch disc contact surface for deformation or damage. Replace if necessary.




SCL219

- Adjust unevenness of diaphragm spring with Tool.

Uneven limit:

0.7 mm (0.028 in)



ST20050240


(-)

FLYWHEEL INSPECTION

- Check contact surface of flywheel for slight burns or discoloration. Repair flywheel with emery paper.
- Check flywheel runout.

Runout (Total indicator reading):


0.15 mm (0.0059 in) or less



SCL349




INSTALLATION

- Insert Tool into clutch disc hub when installing clutch cover and disc.



SCL261

CLUTCH DISC AND CLUTCH COVER



Clutch Disc INSPECTION

- Check clutch disc for wear of facing.

Wear limit of facing surface to rivet head:
0.3 mm (0.012 in)

- Check clutch disc for backlash of spline and runout of facing.

Maximum backlash of spline (at outer edge of disc):
0.9 mm (0.035 in)

Runout limit:
1.0 mm (0.039 in)

Distance of runout check point (from hub center)
107.5 mm (4.23 in)

- Check clutch disc for burns, discoloration or oil or grease leakage. Replace if necessary.

INSTALLATION

- Apply recommended grease to contact surface of spring portion.

Too much lubricant might damage clutch disc facing.